



Philips
PC Headset

SHM7110



Customizable PC headset

Your perfect notebook and desktop companion

This sleek PC solution lets you tailor your headset with customizable earshells. With crystal-clear voice transmission and a comfortable headband design, you can chat away the hours in comfort.

Enrich your PC experience

- Customizable ear shells

Quality sound performance

- 40mm speaker driver delivers sound without distortion

Clear voice transmission

- Highly sensitive microphone for clear voices pick up

Easy and comfortable to wear

- Ear cushions improve wearing comfort and bass response
- Personalize the fit for extra comfort during extended use

Ultimate Convenience

- In-line mute & volume control

PHILIPS

sense and simplicity

Specifications

Design

- Wearing style: Headband

Sound

- Acoustic system: Semi-open
- Magnet type: Neodymium
- Frequency response: 18 - 22 000 Hz
- Impedance: 32 Ohm
- Maximum power input: 100 mW
- Microphone cartridge: 6 mm
- Sensitivity: 110 dB
- Speaker diameter: 40 mm
- Type: Dynamic
- Sensitivity microphone: 20-10 000 Hz, -40 dB

Connectivity

- Cable length: 2 m
- Connector: 2 x 3.5 mm
- Type of cable: Copper

Convenience

- Volume control
- Mute switch

Product dimensions

- Product dimensions (W x H x D):
16.5 x 19 x 6.8 cm
- Weight: 0.113 kg

Packaging dimensions

- Packaging dimensions (W x H x D):
20.5 x 26.5 x 8.3 cm
- Gross weight: 0.241 kg
- Nett weight: 0.113 kg
- Tare weight: 0.128 kg
- EAN: 87 12581 43963 7
- Number of products included: 1
- Packaging type: Blister

Inner Carton

- Inner carton (L x W x H): 42 x 26.5 x 28.2 cm
- Gross weight: 1.9 kg
- Nett weight: 0.678 kg
- Tare weight: 1.222 kg
- EAN: 87 12581 43965 1
- Number of consumer packagings: 6

Outer Carton

- Outer carton (L x W x H): 55 x 44.5 x 61 cm
- Gross weight: 10 kg
- Nett weight: 2.712 kg
- Tare weight: 7.288 kg
- EAN: 87 12581 43964 4
- Number of consumer packagings: 24

Highlights

Customizable PC headset

Customizable earshells on this PC headset allows you to differentiate yourself with shells that match your personal style.

Comfort ear cushions

The special shape and luxurious materials used for the ear cushions of these Philips headphones ensure a perfect fit for maximum comfort. They prevent audio leakage and enhance bass performance too. The ear cushions are shaped in such a way that they perfectly align with the area around a person's ear.

40 mm speaker driver

The 40 mm speaker driver is made of a composite mylar material for a highly sensitive yet powerful element that delivers sound without audible distortion.

Highly sensitive microphone

For clear and uninterrupted online conversations, this PC headset is the perfect solution as it comes with a highly sensitive microphone that picks up your voices.

Adjustable Comfort level

No matter how you like to 'feel' your headphones, this unique headband construction will always provide you with a personalized, comfortable fit. With height adjustment, you can comfortably wear the headphone for a much longer period.

In-line mute & volume control

Mute your voice or adjust the volume without having to go to the audio source device.



Issue date 2012-07-31

Version: 5.2.7

12 NC: 8670 000 41846
EAN: 87 12581 43963 7

© 2012 Koninklijke Philips Electronics N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips
Electronics N.V. or their respective owners.

www.philips.com