

Philips Classic micro sound system

Dock for iPod





# Obsessed with sound

# Relax to great music

Experience your iPod music in superb sound quality with the DC156. Just dock your iPod and enjoy music the way you like it. DC156 also offers fast and precise tuning via its 40 preset stations.

### Enjoy your music from multiple sources

- Play and charge your iPod simultaneously
- Play CD, CD-R and CD-RW
- MP3 Link for portable music playback
- Digital tuning with preset stations for extra convenience

### Enrich your sound experience

- Dynamic Bass Boost for deep and dramatic sound
- Digital Sound Control for optimized music style settings

### Easy to use

- Single remote control for the system and iPod
- Wake up and sleep timer functions



# Specifications

#### **Audio Playback**

- Playback Media: CD, CD-R, CD-RW
- · Disc Playback Modes: 20-Track Programmable, Repeat/one/all/program, Fast Forward/Backward, Next/Previous Track Search, Shuffle Play
- Loader Type: Top
- Cradle playback mode: Charging iPod, Fast forward and backward, Next and Previous track, Play and Pause

### Sound

- Output Power: Total 15W RMS
- · Volume Control: Volume Control up/down
- · Sound Enhancement: Dynamic Bass Boost
- Sound System: Stereo

### Loudspeakers

• Main Speaker: 3" woofer, Bass Reflex Speaker System

### **Tuner/Reception/Transmission**

- Tuner Bands: FM Stereo, MW
- · Auto digital tuning
- Station presets: 20
- Tuner Enhancements: Auto Store

## Connectivity

- · Headphone: 3.5 mm
- · Other connections: FM fixed pigtail antenna, AM Antenna
- Audio Connections: 3.5mm Line in

## Rewritable







### Convenience

- Alarms: Sleep timer, Radio Alarm, CD Alarm
- · Clock: On main display
- Display Type: LCD
- Backlight color: Blue
- Backlight

### Accessories

- Included accessories: FM/MW Antenna, World Wide Warranty leaflet, IFU / User Manual
- Remote control: 24-key remote control
- Cradle: Adaptors for iPod
- · Quick start guide: English
- User Manual: English

### **Dimensions**

- Set dimensions (W x H x D): 148 x 233 x 216 mm
- Main speaker dimensions (W x H x D): 134 x 230 x 152 mm
- Packaging dimensions (W x H x D): 370 x 326 x 270 mm
- Weight incl. Packaging: 4.83 kg

### Power

Made fo

• Power supply: 220-240V, 50Hz

### iPod compatibility

· Compatible with: iPod mini, iPod nano, iPod with color display, iPod 5th Generation, iPod classic

## DC156/05

# Highlights

### Play and charge your iPod

Enjoy your favorite MP3 music while charging your iPod! The dock lets you connect your iPod directly to the Docking entertainment system so you can listen to your favorite music in superb sound. It also charges your iPod while it plays so you can enjoy your music and not have to worry about your iPod battery running out. Use the remote control to navigate, select and playback the music stored on your iPod. The Docking entertainment system automatically charges your iPod while it is docked.

### **Dynamic Bass Boost**

Dynamic Bass Boost maximizes your music enjoyment by emphasizing the bass content of the music throughout the range of volume settings from low to high - at the touch of a button! Bottomend bass frequencies usually get lost when the volume is set at a low level. To counteract this, Dynamic Bass Boost can be switched on to boost bass levels, so you can enjoy consistent sound even when you turn down the volume.



EAN: 87 12581 58196 1