



Philips  
Micro music system

with 30-pin connector

for iPod/iPhone/iPad  
CD, MP3-CD, USB, FM  
120W, Bass radiator

DCM3020



# Rich and powerful sound

## Obsessed with sound

Fill your home with tunes from your iPod/iPhone/iPad. Let the trendy Philips Micro sound system set your music free with details and the powerful bass of wOOx technology. Simply dock your device as it is, even if it is in a protective case.

### Enjoy your music from multiple sources

- Play and charge your iPod/iPhone/iPad
- USB Direct for MP3/WMA music playback
- Play MP3/WMA-CD, CD and CD-RW
- MP3 Link for portable music playback

### Enrich your sound experience

- wOOx™ loudspeaker Technology for deep and powerful bass
- Dome tweeter for detailed and natural sound
- Digital Sound Control for optimised music style settings
- Dynamic Bass Boost for deep and dramatic sound
- 120 W RMS total output power

### Easy to use

- Motorised CD loader for convenient access
- Radio Data System for station information and data services
- All-in-one remote control for your system and iPod/iPhone/iPad

**PHILIPS**

# Highlights

## Play and charge iPod/iPhone/iPad



Enjoy your favourite MP3 music while charging your iPod/iPhone/iPad! The dock lets you connect your portable device directly to the Philips system so you can listen to your favourite music in superb sound. It also charges your iPod/iPhone/iPad while it plays so you can enjoy your music and not have to worry about your portable player battery running out. The system automatically charges your portable device while it is docked.

## wOOx™ Technology

wOOx technology is a revolutionary loudspeaker concept that allows you to hear and feel profoundly deep bass that is richer than any other audio system. Special speaker drivers work in harmony with the wOOx bass radiator, and precise tuning between the main driver and the tweeter ensures smooth transitions from low-mid to high frequencies. Dual suspension and a totally symmetrical sandwich construction deliver low and precise base without noticeable distortion. wOOx produces exceptionally deep and dynamic bass by using the speaker box full volume to truly magnify the impact of the music.

## Dome tweeter

Dome tweeters reproduce clear high and mid-range frequencies that enhance the overall sound clarity coming from the speakers. Delivering a harmonious blend of undistorted

and uncoloured wide-ranging sound, they offer detailed vocal clarity and instrument tone purity, thereby balancing the overall sound when paired with a combination of woofers.

## USB Direct



With the USB Direct mode, simply plug in your USB device to the USB port on your Philips device and your digital music will be played directly from the Philips device.

## Digital Sound Control



Digital Sound Control offers you a choice of pre-set Jazz, Rock, Pop and Classical controls you can use to optimise the frequency ranges for different musical styles. Each mode uses graphic equalizing technology to automatically adjust the sound balance and enhance the most important sound frequencies in your chosen music style. Ultimately, Digital Sound Control makes it easy for you get the most out of your music by precisely adjusting the sound balance to match the type of music you are playing.

## Dynamic Bass Boost



Dynamic Bass Boost maximises your music enjoyment by emphasising the bass content of the music throughout the range of volume settings - from low to high – at the touch of a button! Bottom-end bass frequencies usually get lost when the volume is set at a low level. To counteract this, Dynamic Bass Boost can be switched on to boost bass levels, so you can enjoy consistent sound even when you turn down the volume.

## MP3 Link



The MP3 link connectivity allows direct playback of MP3 content from portable media players. Besides the benefit of enjoying your favourite music in the superior sound quality delivered by the audio system, the MP3 link is also extremely convenient as all you have to do is to plug your portable MP3 player into the audio system.

# Specifications

## Sound

- Output power (RMS): 2 x 60 W
- Sound Enhancement: Digital Sound Control, Dynamic Bass Boost, Loudness

## Loudspeakers

- Loudspeaker types: Dome tweeter
- Main Speaker: 2-way, wOOx Bass Radiator

## Audio Playback

- Playback Media: CD, CD-R, CD-RW, MP3-CD, WMA-CD, USB flash drive
- Disc Playback Modes: Repeat/one/all/programme, Shuffle Play, 20-Track Programmable, Fast Forward/Reverse, Next/Previous Track Search
- Loader Type: Motorised, Tray
- ID3-tag support
- USB Direct Modes: Fast Reverse/Fast Forward, Play/Pause, Previous/Next, Programme Play, Repeat, Shuffle, Stop
- Cradle playback mode: Charging iPod, Charging iPhone, Charging iPad, Fast forward and reverse, Next and Previous track, Play and Pause, Menu, Up and Down

## Tuner/Reception/Transmission

- Tuner Bands: FM Stereo
- Auto digital tuning
- Tuner Enhancements: Auto Store
- RDS: Programme Type, Station Name, Radio Text
- Station presets: 20

## Connectivity

- USB: USB host
- Headphones: 3.5 mm
- 3.5 mm stereo line in: MP3 Link
- Rear Connections: AUX in, FM Antenna, Left and right speakers

## Convenience

- Alarms: CD Alarm, Radio Alarm, USB alarm, iPod

## Alarm

- Clock: On main display
- Display Type: VFD display

## Accessories

- Included accessories: AC Power Cord, FM antenna, MP3 Link Cable
- Remote control
- User Manual
- Quick start guide
- Warranty: Worldwide Guarantee booklet

## Dimensions

- Main speaker dimensions (W x H x D): 139 x 304 x 230 mm
- Set dimensions (W x H x D): 230 x 141 x 230 mm
- Packaging dimensions (W x H x D): 512 x 346 x 276 mm
- Gross weight: 8.6 kg
- Net weight: 7.3 kg

## Power

- Power supply: 220-240 V, 50 Hz

## iPhone compatibility

- Compatible with: iPhone, iPhone 3G, iPhone 3GS, iPhone 4

## iPod compatibility

- Compatible with: iPod nano 1st generation, iPod nano 2nd generation, iPod nano 3rd generation, iPod nano 4th generation, iPod nano 5th generation, iPod nano 6th generation, iPod touch, iPod touch 2nd Generation, iPod touch 3rd generation, iPod touch 4th generation, iPod 5th generation, iPod 6th Generation

## iPad compatibility

- Compatible with: iPad



Issue date 2014-07-18

Version: 1.1.8

12 NC: 8670 000 75911  
EAN: 87 12581 60231 4

© 2014 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)