



Philips  
Headphones

In-ear

SHE2100WT

## Earbud comfort

Large speakers for extra bass

With 15mm speakers, these earbud headphones are valued for the bass sound. Ergonomics design with slim rubberized caps for long hours of comfort listening.

### Music to your ears

- 15mm speaker driver optimizes wearing comfort
- Bass beat vents allow air movement for better sound
- Neodymium magnets enhance bass performance and sensitivity

### Made to fit you and your lifestyle

- Slim cap earbud design for best comfort fit
- Super soft rubber caps for sensational comfort

**PHILIPS**

# Specifications

## Sound

- Acoustic system: open
- Magnet type: Neodymium
- Voice coil: copper
- Diaphragm: Mylar dome
- Impedance: 16 ohm
- Maximum power input: 25 mW
- Sensitivity: 107 dB
- Speaker diameter: 14.8 mm
- Type: Dynamic
- Frequency response: 10 - 22 000 Hz

## Design

- Color: White

## Connectivity

- Cable Connection: two-parallel, symmetric
- Cable length: 1 m
- Connector: 3.5 mm
- Finishing of connector: nickel plated
- Type of cable: copper

## Outer Carton

- GTIN: 1 69 23410 73075 0
- Number of consumer packagings: 24
- Gross weight: 1.162 kg
- Gross weight: 2.562 lb
- Outer carton (L x W x H): 34.5 x 19.7 x 16.3 cm
- Outer carton (L x W x H): 13.6 x 7.8 x 6.4 inch
- Nett weight: 0.523 lb
- Nett weight: 0.23712 kg
- Tare weight: 0.92488 kg
- Tare weight: 2.039 lb

## Packaging dimensions

- Number of products included: 1
- Packaging type: Blister
- Type of shelf placement: Both
- EAN: 69 23410 73075 3
- Packaging dimensions (W x H x D): 5 x 17.275 x 2.4 cm
- Packaging dimensions (W x H x D): 2 x 6.8 x 0.9 inch
- Gross weight: 0.064 lb
- Gross weight: 0.02915 kg
- Nett weight: 0.022 lb
- Nett weight: 0.00988 kg
- Tare weight: 0.01927 kg
- Tare weight: 0.042 lb

## Inner Carton

- Gross weight: 0.258 lb
- Gross weight: 0.117 kg
- GTIN: 2 69 23410 73075 7
- Inner carton (L x W x H): 7 x 3.1 x 2.4 inch
- Inner carton (L x W x H): 17.9 x 8 x 6 cm
- Nett weight: 0.065 lb
- Nett weight: 0.02964 kg
- Number of consumer packagings: 3
- Tare weight: 0.193 lb
- Tare weight: 0.08736 kg

## Product dimensions

- Product dimensions (W x H x D): 1.6 x 2.1 x 1.25 cm
- Product dimensions (W x H x D): 0.6 x 0.8 x 0.5 inch
- Weight: 0.00988 kg
- Weight: 0.022 lb

# Highlights

## 15 mm speaker driver

Small enough for optimum wearing comfort and big enough to deliver crisp, non-distorted sound, the 15 mm speaker driver is an ideal size for listening enjoyment.

## Bass Beat vents

Bass beat vents allow air movement for better sound with a deep rich bass.

## Neodymium magnets

Neodymium is the best material for producing a strong magnetic field for greater sensitivity in a voice coil, better bass response and higher overall sound quality.

## Slim cap earbud design

Slim cap is ergonomically designed according to the anatomy of the human ear canal. It fits in the ear securely and comfortably for earbud lovers.

