

Philips
MP3/WMA Mini Hi-Fi
System



FWM572



Enjoy digital music via USB Direct playback

Fulfil all your music needs with this MP3/WMA Mini Hi-Fi System. Enjoy your digital music in a high power system via the USB Direct and savour 60 hours of your favourite MP3/WMA-CD music. Intuitive ease-of-use make this set a joy to use!

Powerful sound you can hear and feel

- 3 way Speaker System with MAX bass port
- 2 x 110W RMS/2 x 220W music power/3000W PMPO

Longer listening, greater enjoyment

- 60 hours of WMA-CD or 30 hours of MP3-CD music playback
- Enjoy MP3/WMA music from your portable USB devices
- 3 CD Changer
- Dual logic tape deck with auto replay

Personalised sound settings

- MAX Sound for instant power boost
- Dynamic Bass Boost delivers deeper, more dramatic bass
- Digital Sound Control for optimised music style settings
- Virtual Ambience Control provides simulated sound settings

PHILIPS

Technical specifications

Sound

- **Output power:** 2x120W music
- **Sound enhancement:** MAX Sound, Incredible surround, Dynamic Bass Boost 3 steps, Digital sound control 4 modes, Virtual Ambience Control

Loudspeakers

- **Main speaker:** 6.5" woofer, 2" tweeter, Piezo, 3 way, Bass reflex speaker system
- **Number of loudspeakers:** 2

Audio Playback

- **Playback Media:** MP3-CD, WMA-CD, CD, CD-R, CD-RW
- **Disc playback modes:** 99 track programmable, Repeat / one / disc / program, Shuffle play
- **ID3 tag support**
- **Loader type:** 3 CD carousel
- **Number of discs:** 3
- **Number of decks:** 2
- **Cassette deck technology:** Full Logical

Audio Recording

- **Tape recording enhancement:** Automatic Recording Level, CD synchro start recording

Tuner / Reception / Transmission

- **Auto digital tuning**
- **RDS:** News, Program type, Radio text, RDS clock set, Station name
- **Station presets:** 40
- **Tuner bands:** FM, MW
- **Tuner enhancements:** Auto store, Easy set up (Plug & Play)

Connectivity

- **USB:** USB host
- **Aux in:** Line in
- **Headphone:** 3.5
- **Other connections:** FM antenna, MW antenna

Convenience

- **Display type:** FTD
- **Clock:** On main display
- **Alarms:** CD alarm, Radio alarm, Sleep timer
- **Eco power standby:** 1 watt
- **Indications:** DIM mode

Accessories

- **Included accessories:** AC power cord, FM/MW antenna, Quick user guide, Guarantee booklet
- **Remote control:** 32-key with 2xAA batteries
- **User manual:** English

Dimensions

- **Set dimensions (W x H x D):**
265 x 310 x 367 mm
- **Main speaker dimensions (W x H x D):**
248 x 310 x 195 mm
- **Packaging dimensions (W x H x D):**
611 x 411 x 440 mm
- **Weight incl. packaging:** 15.6 kg

Power

- **Power supply:** 200-240 V, 50Hz
- **Standby power consumption:** <1 W

Product highlights

Play music via USB Direct

Simply plug in your device to the USB port on your Philips Hi-Fi system. Your digital music will be played directly from the device. Now you can share your favourite moments with family and friends.

MAX Sound

MAX Sound technology produces an instant boost in bass, maximises volume performance, and instantly creates the most impressive listening experience with just a touch of the MAX Sound button. The MAX Sound electronic circuitry calibrates the existing sound and volume setting, and instantly boosts bass and volume to a maximum level without distortion. Both sound spectrum and volume get noticeably amplified, creating a potent audio boost that will add mileage to any music. MAX Sound lets you get the most from your audio system without having to alter complicated equaliser settings.

2x110W RMS/2x220W music power

60 hours of WMA-MP3-CD music

3 CD Changer

Dynamic Bass Boost

Dynamic Bass Boost maximises your music enjoyment by emphasising the bass content of the music throughout the range of volume settings - from low to high - at the touch of a button! Bottom-end bass frequencies usually get lost when the volume is set at a low level. To counteract this, Dynamic Bass Boost can be switched on to boost bass levels, so you can enjoy consistent sound even when you turn down the volume.

Digital sound control

Digital Sound Control lets you select from pre-set modes that control the frequency bands of sound to optimise certain musical styles. You can choose between different sound settings - Optimal, Jazz, Rock, Techno, Pop or Classic. Each mode uses graphic equalising technology to automatically adjust the sound balance and enhance the most important sound frequencies in your chosen music style. Digital Sound Control lets you get the most out of your music by adjusting the sound balance to match the music type you are playing.

Virtual Ambience Control

Virtual Ambience Control (VAC) creates a virtual sound environment in which the listener can experience music as it would sound in various simulated sound settings. VAC sound settings digitally mimic the acoustical effects that are characteristic of special rooms and environments such as Hall, Cinema, Arcade, Concert, Disco, and Cyber. By recreating the sound ambience of different environments and settings, VAC dramatically enhances enjoyment of your favourite music.

3 way spk sys with MAX port

Dual logic tape deck



Date of issue 2006-08-23

Version: 1.0

12 NC: 9073 100 13055
EAN: 87 10895 93026 0

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.
© 2006 Koninklijke Philips Electronics N.V.
All Rights reserved.
www.philips.com

* Music with Digital Right Management not supported.