

Philips  
Car audio system

- for iPhone & iPod
- USB
- CD

CEM3000



## Seamless music enjoyment on the road

with iPhone/iPod music playback

Enjoy music from your iPhone/iPod, CD or USB devices out loud with the Philips car audio system. Treat your ear to powerful bass with MAX Sound, and your eye to the variable color LCD display for a personalized backlight color.

### Enjoy your digital music in car

- Play & charge your iPod / iPhone
- Enjoy MP3/WMA music directly from your portable USB drives
- CD player and MP3 Link for music playback

### Superb performance in a compact design

- MAX Sound for instant power boost
- Dynamic Bass Boost electronically enhances the low tones
- Super anti-shock protection for smooth music enjoyment
- 3-band parametric equalizer with 8 presets
- Audio out for amplifier addition
- Built-in 50W x 4 amplifiers for excellent sound quality

### Design that blends into your car

- High contrast LCD with 32K variable color illuminations
- Browse by folder or song for instant search or quick access
- Detachable front panel and blackout for anti-theft security

# PHILIPS

# Highlights

## MAX Sound



MAX Sound technology produces an instant boost in bass, maximizing volume performance and instantly creating the most impressive listening experience with just the touch of a button. Its sophisticated electronic circuitry calibrates existing sound and volume settings, instantly boosting bass and volume to maximum levels without distortion. The end result is a noticeable amplifying of both sound spectrum and volume and a potent audio boost that will add mileage to any music.

## DBB Dynamic Bass Boost



Activate the Dynamic Bass Boost (DBB), and the low-end bass frequencies are electronically enhanced to achieve consistent sound reproduction, especially when the speaker

volume is set at a low level. You hear impressive bass at all times.

## 3-band parametric equalizer

3-band parametric equalizer with 8 presets

## 32K variable color LCD



High contrast LCD with 32K variable color illuminations

## Browse by folder or song



This function allows you to find a track or album much faster by letting you browse through songs and folders, which are the usual contents of USB/SDHC devices. With the dedicated folder/song button, only three

simple steps are needed to make a search – press folder/song, rotate the volume knob and push to select. This simple process lets you search through your music quickly and easily, letting you to focus on your driving.

## USB Direct for MP3/WMA music



Simply plug in your device to the USB port on your Philips Hi-Fi system. Your digital music will be played directly from the device. Now you can share your favorite moments with family and friends.

## Detachable front panel



Detachable front panel and blackout for anti-theft security



# Specifications

## Display

- Type: High contrast LCD, 32K color illuminations (11 characters)
- Key illumination: White

## Audio Playback

- Playback Media: CD, CD-R, CD-RW, MP3-CD, WMA, WMA-CD, USB flash drive
- Compression format: MP3, WMA
- Disc Playback Modes: Fast Forward/Backward, Introscan, Next/Previous Album Search, Next/Previous Track Search
- ID3 Tag support: Song title, artist, album
- MP3 bit rates: 32-320kbps and variable bit rate
- USB Direct Modes: Play/Pause, Previous/Next, Fast Backward/Fast Forward, Repeat, Shuffle

## Tuner/Reception/Transmission

- Tuner Bands: AM, FM Stereo
- Auto digital tuning
- Tuner Enhancements: Auto search and store
- No. of preset stations: 18(FM), 12(AM)
- RDS: Station Name, Station Information, Radio Text, Program Type, News, News & Traffic, RDS Clock Set

## Sound

- Equalizer: 3-bands
- Equalizer settings: Classic, Jazz, Pop, Rock, Flat, Optimal, Techno, User defined

- Sound Enhancement: MAX Sound, Dynamic Bass Boost
- Output power (MAX): 50Wx4 channels
- Output power (RMS): 24Wx4 channels (4 ohms, 10% T.H.D.)

## Connectivity

- USB: USB 2.0 Host
- MP3-Link: For portable MP3 music playback
- Preamp output: 2 pairs RCA(L/R)
- Sub-woofer preamp output: With gain control

## Security/Anti-theft

- Front panel: Detachable
- Display blackout: 10/20 sec selectable

## Accessories

- Remote control: Slim remote with battery
- User Manual: Brazilian Portuguese, Spanish
- Quick start guide: English, Traditional Chinese, Brazilian, Portuguese, Spanish

## Power

- Power supply: 12V DC

## Dimensions

- Product dimensions (W x H x D):  
188 x 58 x 190 mm
- Chassis: 1 Din



Issue date 2013-05-10

Version: 3.0.4

12 NC: 8670 000 65476  
EAN: 69 23410 70349 8

© 2013 Koninklijke Philips Electronics N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips  
Electronics N.V. or their respective owners.

[www.philips.com](http://www.philips.com)