



Philips  
Micro Hi-Fi System

Made for iPod  
MP3/WMA-CD playback

MCM138D

## Obsessed with sound

Relax with great music

Dock your iPod player. Listen to your music from one simple control. Great sound and stylish design. Sit back and relax, enjoy your music all day, your way.

### Fits any space, any lifestyle

- Play and charge your iPod simultaneously
- One remote control for both system and iPod
- Compact design

### Enrich your sound experience

- Play MP3/WMA-CD, CD and CD-RW
- Digital Sound Control for optimized music style settings
- Dynamic Bass Boost for deep and dramatic sound
- 4W RMS total output power

### Wake up to CD or radio tunes

- Wake up and sleep timer functions
- Stereo tuning with digital readout

# PHILIPS

# Highlights

## Digital Sound Control

Digital Sound Control offers you a choice of pre-set Jazz, Rock, Pop and Classic controls you can use to optimise the frequency ranges for different musical styles. Each mode uses graphic equalizing technology to automatically adjust the sound balance and enhance the most important sound frequencies in your chosen

music style. Ultimately, Digital Sound Control makes it easy for you get the most out of your music by precisely adjusting the sound balance to match the type of music you are playing.

## Dynamic Bass Boost

Dynamic Bass Boost maximizes your music enjoyment by emphasizing the bass content of

the music throughout the range of volume settings - from low to high – at the touch of a button! Bottom-end bass frequencies usually get lost when the volume is set at a low level. To counteract this, Dynamic Bass Boost can be switched on to boost bass levels, so you can enjoy consistent sound even when you turn down the volume.



# Specifications

## Sound

- Output power: 2 x 2 W RMS / 200 W PMPO
- Sound enhancement: Dynamic Bass Boost, digital sound control
- Volume control: up/down

## Loudspeakers

- Speaker drivers: 3.5" woofer
- Speaker types: bass reflex speaker system

## Audio playback

- Playback media: CD, CD-R, CD-RW, MP3-CD, WMA-CD
- Disc playback modes: repeat/shuffle/program
- Docking playback modes: fast forward and backward, menu, up and down, next and previous track, play and pause

## Tuner/Reception/Transmission

- Tuner bands: FM stereo, MW
- Antenna: MW antenna

## Connectivity

- Audio/Video output: Headphone (3.5mm)
- Others: cradle connection

## Convenience

- Alarms: CD alarm, radio alarm
- Clock: on main display, sleep timer
- Loader type: top

- Display type: LCD display
- Backlight color: white
- Charging device: iPod

## Accessories

- Remote control: 20-key with lithium battery
- Others: cradle and adaptors for iPod, MW loop antenna, Quick start guide
- User Manual: English, Traditional Chinese
- Warranty: World Wide Guarantee booklet

## Dimensions

- Gross weight: 5.27 kg
- Main speaker dimensions (W x D): 150 x 204 mm
- Main speaker height: 153 mm
- Main unit depth: 244 mm
- Packaging width: 302 mm
- Main unit height: 153 mm
- Packaging height: 531 mm
- Main unit width: 150 mm
- Packaging depth: 202 mm

## iPod compatibility

- Compatible with: iPod, iPod mini, iPod nano, iPod with color display, iPod 5th generation

## Power

- Power supply: 50/60 Hz
- Power supply: 110 - 240 V



Issue date 2014-02-07

Version: 1.0.3

12 NC: 8670 000 38706  
EAN: 87 12581 41019 3

© 2014 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)