

Philips Alarm clock

Bluetooth® Dual USB port for charging Dual alarm Natural sound

AJT600

Charge your mobile devices while sleeping

With two USB slots, this Philips alarm clock provides a convenient way to keep your devices ready to go. Wake up to the alarm buzzer or restful nature sounds, with big knobs at the front for simple alarm and time setup.

Simplicity in use

· Works with any Bluetooth-enabled device

Convenient bedside battery charger

- Extra USB for charging an additional smartphone or tablet
- Supports major smartphones and other USB-charged devices

Easy to use

- · Big knobs for intuitive time and alarm setup
- Audio-in for easy portable music playback
- Time and alarm backup for on-time wakeup even with power cut
- Sleep timer for easy falling asleep to your favorite music

Start the day your way

- Dual alarm to wake you and your partner at different times
- · Wake up to sound of nature for a pleasant morning experience
- · Gentle wake for a pleasant wake up experience
- Repeat alarm for additional snooze



Alarm clock Bluetooth® Dual USB port for charging, Dual alarm, Natural sound

Highlights

Bluetooth-enabled

Bluetooth is a short range wireless communication technology that is both robust and energy-efficient. The technology allows easy wireless connection to other Bluetooth devices, so you can play your favorite music from any smartphones, tablets or even laptops including iPod or iPhone on Bluetooth-enabled speaker easily.

Additional USB

Extra USB for charging an additional smartphone or tablet

Supports various devices

Supports major smartphones and other USB-charged devices

Big knobs at the front

Big knobs for intuitive time and alarm setup

Wake up to sound of nature

Wake up to sound of nature for a pleasant morning experience

Dual alarm



The Philips audio system comes with two alarm times. Set one alarm time to wake you up and the other time to wake up your partner.

Gentle wake



Start your day right by waking up gently to a gradually escalating alarm volume. Normal alarm sounds with a preset volume are either too low to wake you up or are so uncomfortably loud that you are rudely jolted awake. Choose to wake up to your favorite music, radio station or buzzer alarm. Gentle wake's alarm volume gradually increases from subtly low to reasonably high in order to gently rouse you.

Repeat alarm



To counter oversleeping, the Philips Clock radio has a snooze feature. Should the alarm ring and you wish to continue sleeping a bit longer, simply press the Repeat Alarm button once and go back to sleep. Nine minutes later the alarm will ring again. You can continue to press the Repeat Alarm button every nine minutes until you turn off the alarm altogether.

Sleep Timer



Sleep timer lets you decide how long you want to listen to music or a radio station of your choice before falling asleep. Simply set a time limit (up to 2 hours) and choose a CD or radio station to listen to while you drift off to sleep. The set will continue to play for the selected duration and then automatically switch off to a power-efficient, silent stand-by mode. Sleep Timer lets you fall asleep to your favorite CD or radio DJ without counting sheep or worrying about wasting power.

Time and alarm backup

When there is a power failure, this intelligent clock will still maintain and keep its reliable time and your settings. The scheduled alarm remains active even when its display is off - all thanks to a pre-installed battery. When the power comes back on, there is no need to adjust the clock or reinstate settings. More amazingly, even if power supply is not restored, the battery provides enough energy for the buzzer to go off at the alarm time you have set - making sure you never wake up late.









Specifications

Bluetooth® wireless technology

• Version: BT 2.1

Clock

- Type: Digital
- Time format: 12H

Alarm

- No. of alarms: 2
- Alarm source: Natural sound, Buzzer
- Snooze (repeat alarm): Yes, 9mins
- 24 hours alarm reset
- Sleep timer: 15/ 30/ 60/ 90/ 120 mins

Convenience

- Display type: LED display
- Backlight color: White
- Display Enhancements: Brightness Control
- Display brightness: High/ Mid/ Low

Loudspeakers

• Built-in speakers: 1

Sound

- Sound System: Mono
- Volume control: up/down

Connectivity

• Audio in (3.5mm)

Power

- Mains power: 100-240V, 50/60 Hz
- Power type: AC Input
- Battery type: AA
- Number of batteries: 2

Dimensions

- Packaging type: D-box
- Product dimensions (WxDxH): 195 x 99.3 x 97 mm
- Packaging dimensions (WxDxH): 273 x 124 x 126
 - mm
- Product weight: 0.78 kg
- Weight incl. Packaging: 1.05 kg

Accessories

Quick start guide World Wide Warranty leaflet



Issue date 2014-08-13

© 2014 Koninklijke Philips N.V. All Rights reserved.

www.philips.com

Version: 1.0.3

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips N.V. or their respective owners.

12 NC: 8670 001 08204 EAN: 00 60958 52352 74 AJT600/37