



Philips
Wireless HiFi Headphone

Over-ear

Black

SHD8600UG



Clear wireless music

Digital wireless

SHD8600UG/10 headphones to freely enjoy TV and music around your home. Digital transmission delivers flawless reception and good sound reproduction. The pivoting ear shells and self-adjusting inner headband offers extra fit and comfort.

Superior listening experience

- Crystal-clear (2.4 GHz) digital transmission
- Acoustically tuned speakers for outstanding sound quality

Provides comfort for prolonged use

- Self adjusting inner headband ensures a comfortable fit
- Pivoting ear-shells ensure a comfortable fit

Ease of use

- Quick charge feature for speedy recharging
- Store your receiver on the convenient docking station

PHILIPS
sense and simplicity

Specifications

Sound

- Acoustic system: Closed
- Magnet type: Neodymium
- Frequency response: 20 - 20 000 Hz Hz
- Signal/noise ratio: >86dB
- Speaker diameter: 40mm
- Sensitivity: 95 dB

Tuner/Reception/Transmission

- Automatic channel selection
- Effective range: 30m
- Modulation: GFSK
- Carrier frequency range: 2400 - 2483.5 MHz
- Channel separation: 60 dB

Convenience

- Automatic power off
- Base Station Features: Power LED Indicator
- Battery low indication
- Battery charging indication
- Operating time: ~10 hours

Accessories

- AC/DC Adaptor: 5V/ 550mA DC
- Battery charger: recharging docking station

Power

- Power supply headphone: 2 x AAA rechargeable

batteries

- Power supply transmitter: 6V/ 550mA DC

Packaging dimensions

- Packaging dimensions (W x H x D):
24 x 32 x 10 cm
- Nett weight: 0.567 kg
- Gross weight: 0.896 kg
- Tare weight: 0.329 kg
- EAN: 69 23410 70875 2
- Number of products included: 1
- Packaging type: Display
- Type of shelf placement: Both

Outer Carton

- Outer carton (L x W x H): 32.5 x 26 x 32.5 cm
- Nett weight: 1.701 kg
- Gross weight: 3.296 kg
- Tare weight: 1.595 kg
- Number of consumer packagings: 3
- GTIN: 1 69 23410 70875 9

Product dimensions

- Product dimensions (W x H x D):
18.5 x 22 x 8.5 cm
- Weight: 0.179 kg

Highlights

2.4 GHz digital transmission

The 2.4 GHz digital transmission prevents compression and data loss between the transmitter and the headphones. The digital signals are converted to analog signals at the end of the transmission process. The end-result is superb sound quality, with smooth acoustics and minimal data loss.

Acoustically tuned speakers

Acoustically tuned speakers produce pure, balanced sound with superb clarity and precision in both the high tones and deep bass levels.

Self adjusting inner headband

The inner headband of these Philips headphones makes it easy to obtain a perfect fit for your head. The mechanism adjusts automatically for comfort.

Smart and quick charging

The smart and quick charge feature enables the battery to be fully recharged within a very short time span. The remaining power capacity present in the battery is determined by an internal circuit, so that the incoming voltage can be optimized for a quick recharge while at the same time maximizing the battery lifespan.



Issue date 2013-02-07

Version: 3.1.7

12 NC: 8670 000 74129
EAN: 69 23410 70875 2

© 2013 Koninklijke Philips Electronics N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips
Electronics N.V. or their respective owners.

www.philips.com