



Philips  
Micro music system

with Lightning connector

for iPod/iPhone/iPad  
CD, MP3-CD, USB, FM  
80W max, 2.1 system



DCM3175



# Sound that fits your home

Obsessed with sound

Compatible with the iPhone 5 & iPad mini's Lightning connector, this Philips micro sound system features an active subwoofer for powerful bass. The angled speaker design gives a wide stereo sound and the mono block design fits any home.

#### Enrich your sound experience

- 2.1 system with a built-in subwoofer
- 80W RMS maximum output power
- Digital Sound Control for optimized music style settings

#### Enjoy your music from multiple sources

- Fast charging and play music via Lightning connector
- Play MP3/WMA-CD, CD and CD-RW
- USB Direct for MP3/WMA music playback
- Audio-in for portable music playback
- FM digital tuning with presets

#### Design that blends into your interior

- Mono block design to fit in anywhere at home

# PHILIPS

Micro music system  
with Lightning connector for iPod/iPhone/iPad, CD, MP3-CD, USB, FM, 80W max, 2.1 system

DCM3175/12

## Highlights

### Play and charge via Lightning



Enjoy your favorite music while charging your iPod/iPhone/iPad via the new Lightning connector! Just dock it directly on the speaker to play your hand-picked tunes in superb sound. It also charges your device quickly while playing, so you don't have to worry about the battery running out.

### USB Direct



With the USB Direct mode, simply plug in your USB device to the USB port on your Philips device and your digital music will be played directly from the Philips device.

### Audio-in



The Audio in connectivity allows direct playback of Audio in content from portable media players. Besides the benefit of enjoying your favorite music in the superior sound quality delivered by the audio system, the Audio in is also extremely convenient as all you have to do is to plug your portable MP3 player to the audio system.

### Digital Sound Control



Digital Sound Control offers you a choice of pre-set Jazz, Rock, Pop and Classic controls you can use to optimise the frequency ranges for different musical styles. Each mode uses graphic equalizing technology to automatically adjust the sound balance and enhance the most important sound frequencies in your chosen music style. Ultimately, Digital Sound Control makes it easy for you get the most out of your music by precisely adjusting the sound balance to match the type of music you are playing.

## Specifications

### Sound

- Sound enhancement: digital sound control
- Volume control: up/down
- Maximum output power (RMS): 80W

### Loudspeakers

- No. of built-in speakers: 5
- Subwoofer type: Active
- Speaker drivers: 3" woofer x2 with tweeters
- Subwoofer drivers: 5.25" x1

### Audio playback

- Disc playback modes: fast forward/backward, next/previous track search, Repeat
- Playback media: CD, CD-R/RW, MP3-CD, USB flash drive, WMA-CD
- USB Direct playback modes: fast backward/fast forward, play/pause, previous/next, repeat, stop
- Docking playback modes: fast forward and backward, menu, up and down, next and previous track, play and pause
- Others: ID3-tag support

### Tuner/Reception/Transmission

- Tuner bands: FM mono, FM stereo
- Station presets: 20
- Antenna: FM antenna
- Tuner enhancement: auto digital tuning, auto scan, Easy set (plug & play)

### Connectivity

- USB: USB host
- Audio in (3.5mm)

### Convenience

- Alarms: CD Alarm, Radio Alarm, USB alarm, iPod Alarm
- Clock: On main display, sleep timer
- Charging device: iPod, iPhone, iPad, iPad Mini
- Display Type: LCD
- Loader type: Front, Slot-in

### Accessories

- Included accessories: AC Power Cord, User Manual
- Remote control: 21-keys remote

### Dimensions

- Set dimensions (W x H x D): 238 x 899 x 234 mm
- Packaging width: 238 mm
- Packaging height: 250 mm
- Packaging depth: 899 mm
- Gross weight: 10.5 kg
- Net weight: 9 kg

### Power

- Power supply: 110-240V, 50/60 Hz

### iPod compatibility

- Compatible with: iPod nano 7th generation, iPod touch 5th generation

### iPhone compatibility

- Compatible with: iPhone 5

### iPad compatibility

- Compatible with: iPad mini, iPad with Retina display



Issue date 2014-06-12

Version: 2.0.7

12 NC: 8670 000 95169  
EAN: 87 12581 66004 8

© 2014 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)