



Philips
Cube micro sound system

CD, MP3-CD, USB, FM

24W max
24W max

MCM1055



Relax with great music

Obsessed with sound

Enjoy your favorite CDs and portable music just the way you like it. The Philips cube micro music system plays CDs and more, it also features USB Direct for portable music playback. The compact design fits any space, any lifestyle.

Enjoy your favorite music

- Play MP3/WMA-CD, CD and CD-RW
- USB Direct for easy MP3 music playback
- FM digital tuning with presets

Superb sound quality

- Dynamic Bass Boost for deep and dramatic sound
- 24W Maximum output power

Design that blends into your interior

- Compact design fits any space, any lifestyle

PHILIPS

Cube micro sound system
CD, MP3-CD, USB, FM 24W max, 24W max

Specifications

Audio playback

- Playback media: CD, CD-R, CD-RW, MP3-CD, WMA-CD
- Disc playback modes: repeat/shuffle/program
- USB Direct playback modes: fast backward/fast forward, play/pause, previous/next, program play, repeat, shuffle, stop

Sound

- Sound enhancement: Dynamic Bass Boost, digital sound control
- Volume control: up/down
- Maximum output power (RMS): 24W

Loudspeakers

- Speaker drivers: 3" woofer

Tuner/Reception/Transmission

- Tuner bands: FM stereo
- Station presets: 20
- Antenna: FM fixed pigtail antenna
- Tuner enhancement: auto digital tuning, auto scan

Connectivity

- Audio/Video output: Headphone (3.5mm)
- MP3 Link: 3.5mm stereo line in

Convenience

- Alarms: USB alarm, CD alarm, radio alarm
- Loader type: top
- Clock: on main display, sleep timer
- Display type: LCD display
- Backlight color: white

Accessories

- Remote control
- Others: Quick start guide
- User Manual: multi-languages
- Warranty: World Wide Guarantee booklet

Dimensions

- Gross weight: 3.4 kg
- Main speaker dimensions (W x D): 140 x 198 mm
- Main speaker height: 143 mm
- Main unit width: 140 mm
- Main unit depth: 210 mm
- Main unit height: 143 mm
- Packaging height: 200 mm
- Packaging depth: 248 mm
- Packaging width: 550 mm
- Net weight: (main unit) 0.91 kg, (speaker box) 2 x 0.72 kg

Power

- Power supply: 110-240V, 50/60Hz



MCM1055/98

Highlights

Play MP3/WMA-CD, CD and CD-RW



Audio compression technology allows large digital music files to be reduced up to 10 times in size without radically degrading their audio quality. MP3 or WMA are two of the compression formats that let you enjoy a world of digital music on your Philips player. Download MP3 or WMA songs from authorized music sites on the Internet or create your own MP3 or WMA music files by ripping your audio CDs and transferring them onto your player.

USB Direct for easy MP3 music



Thanks to the complete file transferability, you can easily enjoy the convenience and fun of accessing more digital music via the built-in USB Direct.

Dynamic Bass Boost



Dynamic Bass Boost maximizes your music enjoyment by emphasizing the bass content of the music throughout the range of volume settings - from low to high - at the touch of a button! Bottom-end bass frequencies usually get lost when the volume is set at a low level. To counteract this, Dynamic Bass Boost can be switched on to boost bass levels, so you can enjoy consistent sound even when you turn down the volume.



Issue date 2014-06-24

Version: 1.0.3

12 NC: 8670 000 90517
EAN: 87 12581 64575 5

© 2014 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com