



## ENGLISH

### Note for mounting

To secure the mounting on wall, a concrete wall is required.

### Use screws to mount the main unit on the wall

1. Use this sheet as a template. Mark the position of the unit on the wall (as illustrated above), and then drill two 6mm diameter holes.
2. Secure the 2 dowels and 2 screws (both supplied) in the holes respectively. Leave a gap of 5 mm between the head of the screw and the wall.
3. Hang the unit on the screws.

## 繁體中文

### 安裝的注意事項

要在牆上穩固安裝，需要混凝土牆壁。

### 使用螺釘將主裝置安裝在牆上

1. 使用此紙板作為模板。在牆上標記裝置的位置（如上述所示），然後鑽兩個直徑為 6 毫米的鑽孔。
2. 分別在鑽孔穩固 2 顆木釘和 2 顆螺絲（均有提供）。在螺絲頭與牆壁之間留下 5 毫米的空隙。
3. 將裝置掛在螺絲上。

\* 掛牆安裝說明

於標記的鑽孔位置在牆上鑽孔。