

Philips
DVD Mini Hi-Fi System

300W
subwoofer
3-disc changer

FWD398



Enjoy DVD and MP3 music in superb sound

with 3 DVD changer

The feature-packed Philips DVD mini hi-fi system will astound and convince you to stay home for your entertainment fix. Enjoy music galore with its 3-disk changer, MAX Sound for instant power boost and 3-step Dynamic Bass Boost.

Enrich your movie experience

- Play DVD, (S)VCD, MP3-CD, CD(RW) and Picture CD
- DivX Ultra Certified for enhanced playback of DivX videos
- Dolby Digital for ultimate movie experience
- 3 DVD Changer

Enrich your sound experience

- Total 300W RMS/ 4200W PMPO output power
- MAX Sound for instant power boost
- 3-step Dynamic Bass Boost for deep bass experience
- Digital Sound Control for optimized music style settings

Continuous enjoyment of your favorite music

- MP3 Link for portable music playback
- Enjoy MP3/WMA music directly from your portable USB drives
- Karaoke for endless singing entertainment
- Stereo cassette deck

PHILIPS

Highlights

DivX Ultra Certified

With DivX support, you are able to enjoy DivX encoded videos in the comfort of your living room. The DivX media format is an MPEG4-based video compression technology that enables you to save large files like movies, trailers and music videos on media like CD-R/RW, and DVD recordable discs. DivX Ultra combines DivX playback with great features like integrated subtitles, multiple audio languages, multiple tracks and menus into one convenient file format.

3 DVD changer

3 DVD Changer

MAX Sound

MAX Sound technology produces an instant boost in bass, maximizing volume performance and instantly creating the most impressive listening experience with just the touch of a button. Its sophisticated electronic circuitry calibrates existing sound and volume settings, instantly boosting bass and volume to maximum levels without distortion. The end result is a noticeable amplifying of both sound spectrum and volume and a potent audio boost that will add mileage to any music.

3-step Dynamic Bass Boost

Dynamic Bass Boost maximizes your music enjoyment by emphasizing the bass content of the music throughout the range of volume settings - from level one to level three - at the

touch of a button! You can customize the bass level that fits your style. Bottom-end bass frequencies usually get lost when the volume is set at a low level. To counteract this, Dynamic Bass Boost can be switched on to boost bass levels, so you can enjoy consistent sound even when you turn down the volume.

MP3 Link

The MP3 link connectivity allows direct playback of MP3 content from portable media players. Besides the benefit of enjoying your favorite music in the superior sound quality delivered by the audio system, the MP3 link is also extremely convenient as all you have to do is to plug your portable MP3 player to the audio system.



Specifications

Sound

- Output power: 4200 W PMPO
- Total Sound Power (RMS): 300 W
- Sound enhancement: MAX sound, Dynamic Bass Boost 3 steps, virtual ambience control, digital sound control, Dolby Digital

Loudspeakers

- Number of speaker boxes: 3
- Speaker drivers: 2" tweeter, 5.25" woofer
- Speaker types: bass reflex speaker system

Video Playback

- DVD region code: 3
- Playback media: DVD, DivX, DVD+R/+RW, DVD-R/-RW, SVCD, video CD, picture CD, DivX Ultra
- Disc playback modes: disc menu, OSD, fast forward, fast backward, slow forward, slow backward, search forward/reverse, resume playback from stop, A-B Repeat, chapter repeat, angle, Zoom
- Video enhancement: progressive scan
- USB Direct Playback: JPEG

Audio playback

- Cassette Playback Modes: semi-auto stop
- Playback media: CD, CD-R, CD-RW, MP3-CD, WMA-CD
- Disc playback modes: repeat/one/all/program, repeat/shuffle/program
- Cassette deck technology: mechanical
- Number of decks: 1
- USB Direct playback modes: fast backward/fast forward, play/pause, previous/next, repeat

Audio recording

- Recording media: tape
- Tape recording enhancement: CD synchro start recording

Tuner/Reception/Transmission

- Tuner bands: FM stereo, MW
- Station presets: 40
- Antenna: FM antenna, MW antenna
- Tuner enhancement: auto digital tuning, auto scan, Easy set (plug & play)

Connectivity

- Microphone: dual microphone sockets
- Audio/Video output: 2xRCA (Audio), component

- video out, composite video (CVBS) out, digital output (cinch), S-Video out
- Aux in: 2xRCA (Audio)
- MP3 Link: 3.5mm stereo line in
- USB: USB host

Convenience

- Alarms: CD alarm, radio alarm, tape alarm
- Number of discs: 3
- Loader type: motorised
- Display type: VFD display
- Clock: on main display, sleep timer
- Karaoke: echo control, key control, MIC volume
- On-Screen display languages: English, French, Portuguese, Russian, Spanish, Thai, Traditional Chinese

Accessories

- Cables/Connection: composite video cable (Y), power cord
- Remote control
- User Manual: English
- Others: batteries for remote control, FM/MW antenna, Quick start guide
- Warranty: World Wide Guarantee booklet

Dimensions

- Gross weight: 20 kg
- Main speaker height: 310 mm
- Main speaker dimensions (W x D): 207 x 215 mm
- Packaging width: 558 mm
- Packaging height: 613 mm
- Packaging depth: 486 mm
- Main unit depth: 365 mm
- Subwoofer depth: 387 mm
- Main unit height: 310 mm
- Subwoofer height: 310 mm
- Main unit width: 265 mm
- Subwoofer width: 200 mm

Power

- Power supply: 100 - 240V AC, 50/60Hz

Digital photo playback

- Playback media: DVD+R/+RW, Kodak Picture CD, picture CD
- Picture Enhancement: flip photos, rotate, slideshow, Zoom
- Picture Compression Format: JPEG



Issue date 2014-02-07

Version: 1.0.3

12 NC: 8670 000 42032
EAN: 87 12581 44106 7

© 2014 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com