



Philips  
Universal remote control

2in1 for TV/DVD

SRU1020



## Handy zapper

Operates more than 800 brands

A simple and smart universal remote control for easy TV zapping through the channels and controlling your DVD or VCR regardless of brand.

### Great convenience

- Ideal zapper now you can enjoy watching your DVD, so easy!
- Ergonomic shape enables comfortable control
- Learning copies favorite functions from original remotes

### Quick and easy set-up

- Automatically searches for your equipment brand
- Ready for use with Philips equipment
- URC support service via dedicated website

# PHILIPS

# Specifications

## Convenience

- Supported devices: TV, VCR, DVD
- TV functions: Program up/down, Volume up/down, mute, Power/standby, 16:9
- DVD functions: Transport keys, Disc menu control
- Number of keys: 14
- Preprogrammed for Philips
- Installation steps: 2
- Regulatory approvals: CE Mark
- Simple system setup
- Language support: GB/F/D/NL/DK/S/N/FIN/I/E/P/GR/RU/SZ/PL
- Splash proof
- VCR functions: Transport keys (6)

## Infrared Capabilities

- Operating distance: 33 ft (10 m)
- Transmitting LEDs: 2
- Universal IR code database
- Carrier frequency range: 24 - 55 kHz

- Transmission angle: 90 degree
- Number of brands in database: Over 800

## Power

- Battery type: AAA
- Number of batteries: 2
- Battery lifetime: 12 Months

## Outer Carton

- Quantity: 6
- EAN/UPC/GTIN: 87 10895 93491 6
- Length: 250 mm
- Width: 181 mm
- Height: 170 mm

## Packaging Data

- Length: 242 mm
- Width: 157 mm
- Height: 27 mm
- EAN/UPC/GTIN: 87 10895 93490 9
- 12NC: 908210006422

# Highlights

## Home entertainment zapper

With this zapper you can instantly control all the basic functions of your TV and DVD player / recorder, now it's much easier and much more fun to watch a DVD or zap through your TV channels.

## Ergonomic design

The smooth rounded shape fits perfectly in your hand for natural, balanced operation. It looks great too!

## Learning favorite keys

To have your 5 favorite functions of your original remote available you can copy the signal transmitted from the original remote. If these are your/or your kids favorite channels you can even lock the remote to see any of the other channels.

## Auto brand search

Getting your new remote control working is simply a case of having your remote automatically search for the most suitable code for your equipment.

## Pre-programmed for Philips

If you have Philips equipment, you can use your universal remote control without programming it because all keys are pre-set for Philips.

## Online URC service

Dedicated support service for your remote control whereby all codes for all brands, are available via the Philips URC website.



Issue date 2014-02-06

Version: 2.0.14

12 NC: 9082 100 06422  
EAN: 87 10895 93490 9

© 2014 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)