

Philips
In-ear true wireless
headphones

Bluetooth®
White

TAT3265WT



Snug Fit, Great Sound and Crystal Call

T3265 dedicates snug and feather light fit, stylish design with IPX4 water-proof for better comfort even in running. Two microphones offer an amazing clear noise cancelling for crystal call. 13mm driver with classy BT chip brings great sound.

Design for convenience

- Touch control to manage the music and call
- Capacitive sensor, Detect the headphone in or out

Easy pairing, Easy use

- IPX4 splash- and sweat-resistant
- Easy way to wake your phone's voice assistant
- Smart pairing, automatically find your bluetooth device

Great sound and call

- Clear Voice Cancelling with 2 MICs
- 13mm driver with BT 5.2 classy BT chip
- Mirroring technology for headphone connection

PHILIPS

In-ear true wireless headphones
Bluetooth® White

Specifications

Accessories

- Quick Start Guide
- USB cable: USB-C cable

Connectivity

- Bluetooth profiles: A2DP, AAC, aptX, AVRCP, HFP, Streaming Format: SBC
- Bluetooth version: 5.2
- Maximum range: up to 10 m
- Microphone: Built-in microphone

Convenience

- Call Management: Answer/End Call, Call on Hold, Reject Call, Switch between 2 calls

Power

- Battery type: Lithium-Ion
- Charging time: 2 hr
- Music play time: 6+18 hr
- Talk time: 4 hrs
- Rechargeable
- Standby time: 25 hr

Sound

- Impedance: 32 ohm
- Sensitivity: 98 dB
- Speaker diameter: 13mm
- Acoustic system: Semi-closed
- Frequency response: 20 - 20 000 Hz

Inner Carton

- Gross weight: 1.12 kg
- GTIN: 2 48 95229 11711 6
- Inner carton (L x W x H): 27 x 10.3 x 16.2 cm
- Nett weight: 0.306 kg
- Number of consumer packagings: 6
- Tare weight: 0.814 kg

Outer Carton

- Gross weight: 4.93 kg
- GTIN: 1 48 95229 11711 9
- Outer carton (L x W x H): 43 x 28.6 x 18.3 cm
- Nett weight: 1.224 kg
- Number of consumer packagings: 24
- Tare weight: 3.706 kg

Packaging dimensions

- Packaging dimensions (W x H x D): 4.4 x 14.7 x 9.4 cm
- EAN: 48 95229 11711 2
- Gross weight: 0.171 kg
- Nett weight: 0.051 kg
- Number of products included: 1
- Packaging type: Box
- Tare weight: 0.12 kg
- Type of shelf placement: Both

Product dimensions

- Product dimensions (W x H): 5.5 x 2.9 cm

TAT3265WT/97

Highlights

IPX4

With an IPX4 rating, these true wireless headphones are resistant to splashing from any direction. They won't mind a little sweat, and you don't need to worry about getting caught out in the rain.

Touch control

Touch control, Use the touch to manage your music and call conveniently. you can play&pause, play previous&next track music and answer or reject the call.

Voice assistant

Wake your phone's voice assistant by touching the earphone, then you can ask the phone to play some music, call or check the weather and more

Capacitive sensor

The built-in capacitive sensor, Music pauses automatically when you take an earphone out. It can prevent the earphones from triggering by mistake

Clear Voice Cancelling

The Clear Voice Cancelling with built-in two microphones give you clear call experience.

Great sound

13mm speaker driver and classy BT 5.2 chip deliver you great sound

Smart pairing

These earphones are ready to pair the instant you open the charging case, Once they are paired, the earphones remember the last device they were paired with

Mirroring

Use the advanced TWS retransmission technology to make the connection more stable without latency between two earphones



Issue date 2022-06-03

Version: 4.0.1

12 NC: 8670 001 73541
EAN: 48 95229 11711 2

© 2022 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com