

Philips
Portable CD Player

AX5311



Slim and Jogproof

with Wearable Remote Control

The AX5311 CD players are the absolute latest in urban portable music. Rugged sophistication meets solid performance in this slim and Jogproof player. Long battery life and a wearable remote control enhance your music enjoyment on the go.

Designed for motion

- na
- Ease-to-read dual LCD display
- Wearable remote control for easy access
- Savor up to 45 hours music playback

Jogproof

- 45-second ESP™

Enhanced bass performance

- Digital Dynamic Bass Boost for optimized bass at any volume
- Stereo headphone with Bass Wave Tech for enhanced bass

Enjoy all kinds of discs

- Plays CD, CD-R and CD-RW discs

PHILIPS
sense and simplicity

Specifications

Sound

- Acoustic Feedback
- D/A converter: 1-bit
- Frequency response: 20 - 20 000 Hz
- Output Power: 2 x 5mW RMS
- Signal to noise ratio: > 85dB
- Sound Enhancement: Digital Dynamic Bass Boost
- Volume Control: digital

Audio Playback

- Playback Media: CD, CD-R, CD-RW
- Disc Playback Modes: 30-Track Programmable, Fast Forward/Backward, Hold, Introscan, Repeat Play, Resume Playback from stop, Shuffle Play
- Electronic Skip Protection(CD): 45

Connectivity

- DC in: 4.0 mm, 4.5V, centre +
- Headphone: 3.5 mm
- Line-out: 3,5 mm

Convenience

- Display Type: LCD
- Indications: battery status, Cd functions, DBB, ESP, time, track
- Remote control: Wearable incord remote control

Accessories

- Headphones: SBC HS383(neckband)
- Included Accessories: User Manual
- Pouch: AY3267
- Remote control: AY3785(6 key incord)

Dimensions

- Ebox dimensions (W x H x D): 0 x 0 x 0 mm
- Housing: Heat Resistant Body
- Master carton dimensions: 221 x 315 x 223 mm
- Master carton weight: 4.18 kg
- Master carton quantity: 3
- Packaging dimensions (W x H x D): 203 x 305 x 71 mm
- Packaging type: Clamshell
- Product dimension (WxDxH) inch: 137.5x137.5x23.3mm
- Product weight: 0.2 kg

Power

- Battery Playing Time CD: 40
- Battery type: AA, AAA, LR03, LR6, UM3, UM4

Product highlights

Slim, sturdy and compact

Ease-to-read dual LCD display

Wearable remote control

Up to 45-hour playback

45-second ESP™

Electronic Skip Protection is a convenient feature that ensures skip-free music even when your CD player is subjected to knocks and jolts while you're jogging or on the move. Devices with Electronic Skip Protection have an intelligent electronic buffer that adjusts both its contents and laser spin speeds automatically to guarantee uninterrupted music listening.

Digital Dynamic Bass Boost

Digital Dynamic Bass Boost is an intelligent bass booster that delivers maximum bass enhancement at high volumes without sound distortion and at low volumes without compromising on bottom-end bass frequencies. Technologically advanced electronics constantly monitor volume and bass levels, precisely calibrating both to prevent sound distortion, thus producing optimized bass. Digital Dynamic Bass Boost enables the enjoyment of superb bass performance - regardless of the chosen volume level.

Bass enhanced stereo headphone

Plays CDs, CD-R and CD-RW



Date of issue 2007-01-15

Version: 1.0

12 NC: 9073 101 01599
UPC: 0 37849 94946 7

© 2007 Koninklijke Philips Electronics N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.

www.philips.com