

Philips
Portable DVD Player



PET836



Slim set with DVD slot

with built-in digital TV receiver

The magic of movies and music comes to life on the tablet-style Philips PET836 with 8.5" LCD display. Enjoy free-to-air digital TV programmes with the built-in digital TV receiver. Comes with Smart Car Mount and USB connector.

Immerse yourself in AV entertainment on the go

- Play DVD, DVD+/-R and DVD+/-RW, (S)VCD, DivX® & MPEG4 movies
- Play MP3/WMA-CD, CD and CD-RW
- Share JPEG image files with Picture CD

Experience the digital interactive TV phenomenon

- Support DVB-T for free-to-air digital TV and radio channels
- 7-day Electronic Programme Guide (EPG)
- Direct Teletext and subtitle function support

For ultimate convenience

- Enjoy up to 3 hours' playback with a built-in battery*
- Smart Car Mount for ease of use
- USB connection for photo and music playback from USB devices
- Protective pouch included

PHILIPS
sense and simplicity

Highlights

Play DVD, DivX and MPEG4



With DivX® support, you are able to enjoy DivX® encoded videos in the comfort of your living room. The DivX® media format is an MPEG4-based video compression technology that enables you to save large files like movies, trailers and music videos on media like CD-R/RW, memory cards and DVD-video. DivX® CDs can be played back on selected DVD players, DVD Recorders and Home Theatre Systems.

Support DVB-T



Expand your entertainment experience and enjoy digital channel programmes - for free. With DVB-T (Digital Video Broadcasting - Terrestrial), you can receive free digital TV and radio programmes in Europe. The signal remains digital with no analogue steps in between, to preserve the highest quality.

Smart Car Mount



To enjoy entertainment on the go, why not bring your portable DVD player from home on

the road with you? A unique Car Mount system ensures ease-of-use, with a quick-release arm that facilitates easy removal of the player when not in use. You can bring the portable DVD player with you, leaving just the Mount behind in the car.

USB connection for photo/music



Simply plug in your portable device to the USB connector on your Philips portable DVD player and playback directly from USB or select your digital music or photos. Now you can share your favourite moments with family and friends.



Specifications

Picture/Display

- Display screen type: LCD TFT
- Diagonal screen size (inch): 8.5 inch
- Resolution: 480(w) x 234(H) x 3(RGB)
- Contrast ratio (typical): 250:1
- Response time (typical): 30 ms
- LCD panel type: Anti-glare polariser

Sound

- Output Power: 250 mW RMS (built-in speakers)
- Output power (RMS): 10 mW RMS (earphone)
- Signal to noise ratio: >76 dB (line out), >62 dB (built-in speakers)

Video Playback

- Playback Media: DVD, Picture CD, SVCD, Video CD, DVD-R/-RW, MP3-CD, CD-R/CD-RW, WMA, DVD+R/+RW, CD
- Disc Playback Modes: A-B Repeat, Angle, Disc Menu, Fast Reverse, Fast Forward, OSD, Repeat, Shuffle Play, Slow Reverse, Slow Forward, Zoom
- Video disc playback system: NTSC, PAL
- Compression formats: MPEG4, Divx

Audio Playback

- Compression format: Dolby Digital, MP3, WMA
- MP3 bit rates: 32 - 320 kbps
- WMA bit rates: 32 - 192 kbps
- Playback Media: CD, CD-R, CD-RW, MP3-CD, WMA-CD
- File systems supported: ISO-9660, Joliet

Connectivity

- TV connection: Antenna
- Headphone jack: 3.5 mm Stereo Headphone x 2
- AV output: Composite (CVBS) x 1
- AV input: Composite (CVBS) x 1

- USB
- Audio Output - Digital: Coaxial (cinch)
- DC in: 9 V

Convenience

- Battery charging indication
- Shock proof

Tuner/Reception/Transmission

- DVB: DVB Terrestrial*

Video Decoding

- Aspect Ratio: 16:9, 4:3
- Reception-Demodulation: COFDM 2K/8K, MPEG-2 DVB compliant, Network: MFN/SFN, QPSK

Accessories

- AC/DC Adapter: DC-in 9 V; 100-240 v, 50/60 Hz
- Cables: 1 x AV Cables
- Car kit: cigarette outlet adapter, 12vDC
- Remote control: AY5506 slim remote
- User Manual: Multi-language
- Smart car mount: 1 pcs
- Pouch: Protective pouch
- Included Accessories: Aerial antenna

Dimensions

- Product dimensions (W x H x D): 256 x 170 x 34.5 mm
- Product weight: 1.1 kg
- Packaging dimensions (W x H x D): 298 x 295 x 63 mm
- Master carton quantity: 3
- Master carton dimensions: 305 x 308 x 200 mm
- Master carton weight: 5.9 kg
- Packaging type: D-box



Issue date 2009-07-17

Version: 1.0.5

12 NC: 8670 000 48687
EAN: 87 12581 45860 7

© 2009 Koninklijke Philips Electronics N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.

www.philips.com

* DivX, DivX Certified and associated logos are trademarks of DivXNetworks, Inc. and are used under licence.

* Windows Media and the Windows logo are trademarks or registered trademarks of Microsoft Corporation in the United States and/or other countries.

* Battery life varies by use and settings.