



Philips  
CD receiver

CAD310

## Enjoy your favorite tracks on the road

### Multiple sources for more choices

- CD player
- Compatible with CD-Recordable and CD-ReWritable
- CD changer control for non-stop music on the road
- FM/MW tuner for radio enjoyment

### Powerful Sound

- 4X45W Maximum music power
- Digital signal processing for clear sound and pure silence

### Easy to use and precise control

- Multi-functional LCD display
- Autostore Programming for one-touch radio tuning
- Digital tuning with preset stations for extra convenience
- Easy Access Keyboard for selecting tracks or radio stations

# PHILIPS

# Specifications

## Sound

- Sound System: Stereo
- Output Power: 4x45W Maximum music power
- Volume Control: rotary
- Equalizer settings: Pop, Rock, Classic, Jazz

## Audio Playback

- Playback Media: CD, CD-R, CD-RW
- Disc Playback Modes: Fast Forward/Backward, Next/Previous Track Search, Repeat Play, 20-Track Programmable
- Loader Type: Slot
- Number of decks: 1
- Programmable Tracks: 20

## Tuner/Reception/Transmission

- Antenna: AM Antenna, FM Antenna
- Auto digital tuning
- Tuner Bands: FM, FM Stereo, AM
- Station presets: 20

## Rewritable



## Convenience

- Display Type: Dot Matrix LCD

## Dimensions

- Product dimensions (W x H x D): 182 x 52 x 180 mm
- Product weight: 2 kg

## Power

- Mains power: 12V DC

## Connectivity

- Aux in: 1X(L/R)/RCA
- Other connections: Line out, Antenna

## Accessories

- Included accessories: User Manual

# Highlights

## CD player

CD player

## CD-R/RW Compatible

CD-Rewritable Compatible means that your audio set can play both CD-Recordable (CD-R) and CD-Rewritable (CD-RW) discs. CD-R discs are recordable once and can be played on any audio CD player while CD-RW discs can be recorded and rewritten multiple times and can only be played back on compatible audio CD players. The laser pick-up and CD decoder circuitry of CD-RW compatible players are specially designed to read the special audio CD-RW phase-change recording layer, ensuring you can always play your home-recorded discs on your audio CD system.

## CD changer control

CD changer control for non-stop music on the road

## FM/MW tuner

FM/MW (AM) stereo tuner

## 4x45W Maximum music power

4X45W Maximum music power

## DSP-Digital signal processing

Advanced digital signal processing technology applied to the entire audio path and it ensures crystal clear sound and pure silence when it is important.

## Multi-functional LCD display

Multi-functional LCD display

## Autostore programming

Autostore Programming is a convenient feature that allows you to tune in to your favorite stations and set station presets by simply pressing a button. Autostore Programming does away with the hassle of manual radio station tuning and setting of presets. A built-in electrical circuit automatically scans local radio station frequencies, locks on to the strongest radio station signals, and assigns them to specific presets.

## Digital tuning with presets

Simply tune into the station that you want to preset, press and hold the preset button to memorize the frequency. With preset radio stations that can be stored, you can quickly access your favorite radio station without having to manually tune the frequencies each time.

## Easy Access Keyboard

The Easy Access Keyboard features a phone-style numerical keypad that is a simple and handy tool for selecting CD tracks, radio presets or tuning in to radio stations. Located conveniently at the front of the set, the ten numerical keys make selection and programming a simple one-touch operation. To select a specific track or choose a tuner preset, simply key in the track number or preset number using the keypad. Tune in to your favorite radio station by simply keying in the frequency. Easy Access Keyboard helps you select a specific track, tuner preset or your favorite radio station.



Issue date 2014-02-07

Version: 2.0.3

12 NC: 9073 100 12426  
EAN: 87 10895 86445 9

© 2014 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)