



Philips
MP3 portable speaker

Universal 3.5mm
Silver



SBA1600



Stereo sound on the go

from a fun, pocket-sized speaker

Move with your music! Enjoy stereo sound wherever you go on a travel speaker with exceptional battery life. Secure the line-in cable to use as a lanyard for easy portability. Inside, a digital amplifier eliminates mobile-phone interference.

Enjoy your music in stereo

- Class 'D' digital amplifier for quality sound performance
- Lightweight, portable design for music enjoyment anytime
- Mobile phone shielding technology for static-free sound
- Universal: works via your device's 3.5mm headphone jack

Take your music with you

- 40 hours of continuous play for worry-free enjoyment
- Battery powered for portability
- Line-in cable becomes a lanyard for easy portability

PHILIPS

MP3 portable speaker
Universal 3.5mm Silver

Specifications

Design and finishing

- Color(s): White

Sound

- Frequency response: 350 - 16,000 Hz
- Impedance: 4
- RMS Power rating: 2 W

Accessories

- Batteries: not included

Power

- Battery type: AAA
- Operating time on battery: 40 hr
- Number of batteries: 3

Packaging dimensions

- Packaging type: Carton
- Number of products included: 1
- Packaging dimensions (W x H x D):
9.5 x 15 x 3.04 cm

- Gross weight: 0.11838 kg
- Nett weight: 0.05912 kg
- Tare weight: 0.05926 kg
- EAN: 87 12581 47705 9

Outer Carton

- Number of consumer packagings: 24
- Outer carton (L x W x H): 43.2 x 23.2 x 20.7 cm
- Gross weight: 3.844 kg
- Nett weight: 1.41888 kg
- Tare weight: 2.42512 kg
- EAN: 87 12581 47706 6

Inner Carton

- Number of consumer packagings: 6
- Inner carton (L x W x H): 20 x 10 x 18.5 cm
- Gross weight: 0.80588 kg
- Nett weight: 0.35472 kg
- Tare weight: 0.45116 kg
- EAN: 87 12581 47707 3

SBA1600/00

Highlights

40 hours of continuous play

Powered by batteries, this speaker offers up to 40 hours of continuous play for worry-free enjoyment when you're listening to your music on the go.

Battery powered

Powered by batteries, it's easy to take with you for enjoyment on the go - anywhere and everywhere.

Class 'D' Amplifier

Class 'D' Digital Amplifier takes an analog signal, converts it into a digital signal and then amplifies the signal digitally. The signal then enters a demodulation filter to give the final output. The amplified digital output delivers all the advantages of digital audio, including improved sound quality. In addition, Class 'D' Digital Amplifier has greater than 90% efficiency compared to traditional AB amplifiers. This high efficiency translates into a powerful amplifier with a small footprint.

Lightweight, portable design



The durable, lightweight material and design mean you can carry the speakers with you wherever you go.

Line-in doubles as lanyard

These speakers are ready to go! When it's time to take your music on the go, reconnect the line-in cable and secure it in place to use as a convenient lanyard.

Mobile phone shielding

Mobile phone shielding technology is an advanced circuitry design that cuts out mobile phone interference to ensure static free sound

Universal 3.5mm headphone jack

Plug and play with any of your mobile devices that have a 3.5mm headphone jack – iPod, iPhone, GoGear, MP3 players, laptops, netbooks, music phones and more.



Issue date 2020-07-09

Version: 3.0.8

12 NC: 8670 000 51527
EAN: 87 12581 47705 9

© 2020 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com