

Philips
Micro music system

Bluetooth®

BTM3160



Rich and powerful sound

Obsessed with sound

Let your portable music play on at home. This Philips micro system comes with USB Direct and Audio in. Even with wireless music streaming via Bluetooth, it gives you fuss-free musical enjoyment.

Enrich your sound experience

- 150W RMS maximum output power
- wOOx™ loudspeaker Technology for deep and powerful bass
- Dome tweeter for detailed and natural sound
- Digital Sound Control

Enjoy your music from multiple sources

- Wireless music streaming via Bluetooth
- Play MP3-CD, CD and CD-R/RW
- USB Direct for easy MP3 music playback
- Audio-in for portable music playback

Easy to use

- Motorized CD loader for convenience access
- Radio Data System for station information and data services

PHILIPS

Highlights

Wireless music streaming



Bluetooth is a short range wireless communication technology that is both robust and energy-efficient. The technology allows easy wireless connection to iPod/iPhone/iPad or other Bluetooth devices, such as smartphones, tablets or even laptops. So you can enjoy your favorite music, sound from video or game wireless on this speaker easily.

wOOx™ Technology



wOOx technology is a revolutionary loudspeaker concept that allows you to hear and feel profoundly deep bass that is richer than any other audio system. Special speaker drivers work in harmony with the wOOx bass radiator, and precise tuning between the main driver and the tweeter ensures smooth transitions from low-mid to high frequencies. Dual suspension and a totally symmetrical sandwich construction deliver low and precise bass without noticeable distortion. wOOx produces exceptionally deep and dynamic bass by using the speaker box full volume to truly magnify the impact of the music.

Audio-in



The Audio in connectivity allows direct playback of Audio in content from portable media players. Besides the benefit of enjoying your favorite music in the superior sound quality delivered by the audio system, the Audio in is also extremely convenient as all you have to do is to plug your portable MP3 player to the audio system.

Dome tweeter

Dome tweeters reproduce clear high and mid-range frequencies that enhance the overall sound clarity coming from the speakers. Delivering a harmonious blend of undistorted and uncolored wide-ranging sound, they offer detailed vocal clarity and instruments tone purity, thereby balancing the overall sound when paired with a combination of woofers.

USB Direct for easy MP3 music



Thanks to the complete file transferability, you can easily enjoy the convenience and fun of accessing more digital music via the built-in USB Direct.

Specifications

Sound

- Maximum output power (RMS): 150W
- Sound Enhancement: Digital Sound Control

Loudspeakers

- Main Speaker: 2 way, wOOx Bass Radiator
- Loudspeaker types: Dome tweeter

Audio Playback

- Playback Media: CD, CD-R, CD-RW, MP3-CD, USB flash drive
- Disc Playback Modes: Repeat/one/all/program, Shuffle Play, 20-Track Programmable, Fast Forward/Backward, Next/Previous Track Search
- USB Direct Modes: Fast Backward/Fast Forward, Play/Pause, Previous/Next, Program Play, Repeat, Shuffle, Stop

Tuner/Reception/Transmission

- Tuner Bands: FM Stereo
- Auto digital tuning
- Tuner Enhancements: Auto Store
- RDS: Program Type, Station Name, RDS Clock Set
- Station presets: 20
- Antenna: FM antenna (75 ohm)

Connectivity

- Other connections: FM Antenna
- 3.5mm stereo line in: Audio in
- Bluetooth: Bluetooth V2.1
- Bluetooth profiles: A2DP, AVRCP
- Headphone: 3.5 mm

Convenience

- Alarms: CD Alarm, Radio Alarm, Sleep timer, USB alarm
- Clock: On main display, sleep timer
- Display Type: VFD display
- Indications: DIM mode

Accessories

- Included accessories: AC Power Cord, FM antenna
- Remote control
- User Manual: Multi-language

Dimensions

- Packaging dimensions (W x H x D): 514 x 290 x 360 mm
- Main unit depth: 237 mm
- Main unit height: 195 mm
- Main unit width: 230 mm
- Main speaker dimensions (W x H x D): 139 x 304 x 216 mm
- Gross weight: 8.8 kg
- Net weight: 7.8 kg

Power

- Power supply: 110-240V, 50/60 Hz



Issue date 2014-07-30

Version: 2.0.3

12 NC: 8670 001 07703
EAN: 87 12581 70008 9

© 2014 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com