



Philips
Wireless HiFi Headphone

Over-ear

SHC8575



Exceptional wireless sound

Stereo headphone

Freedom to enjoy music at home. HiFi sound reproduction with auto tuning and bass enhancement features, this Philips SHC8575/10 stereo headphone is the ultimate in personal convenience.

You'll forget you're wearing them!

- Soft ear and headband cushions ensure comfort in use
- 3-way adjustment for a better fit and bass performance
- Preformed soft ear-cushions ensure a comfortable fit

The perfect wireless listening experience

- Bass boost feature reinforces bass reproduction
- Convenient automatic tuning ensures best reception
- 40mm speaker driver delivers sound without distortion

Always ready to go

- FM Wireless transmission for freedom of movement
- Simple, convenient charging with a wireless dock

PHILIPS

Specifications

Sound

- Acoustic system: closed
- Frequency response: 9 - 21 000 Hz
- Magnet type: Neodymium
- Sensitivity: 100 dB
- Speaker diameter: 40 mm
- Signal/noise ratio: 70 dB

Tuner/Reception/Transmission

- Channel separation: >30 dB
- Pilot tone frequency: 19
- Effective range: 100 m
- Carrier frequency range: 863.0 - 865.0 MHz
- Modulation: FM
- Channel selection: automatic
- Number of channel: 3

Convenience

- Automatic power off
- Battery charging indicator
- Low battery indicator
- Double PLL
- Operating time: +/- 15 hours

Power

- Power supply headphone: 2 x 1.5 V NiMH R03/

AAA

- Power supply transmitter: AC/DC adapter 12V/200mA

Outer Carton

- Gross weight: 3.75 kg
- Outer carton (L x W x H): 39 x 26 x 32.5 cm
- Nett weight: 1.992 kg
- Tare weight: 1.758 kg
- GTIN: 1 69 23410 71056 1
- Number of consumer packagings: 3

Packaging dimensions

- Packaging dimensions (W x H x D): 24 x 32 x 12.2 cm
- Gross weight: 1.04 kg
- Nett weight: 0.664 kg
- Tare weight: 0.376 kg
- EAN: 69 23410 71056 4
- Number of products included: 1
- Packaging type: Carton
- Type of shelf placement: Both

Product dimensions

- Product dimensions (W x H x D): 19.5 x 20 x 10 cm
- Weight: 0.316 kg

Highlights

Soft ear and headband cushions

The durable and soft materials used for the ear cushions and headband cushion of these Philips headphones ensure comfortable prolonged use.

3-way adjustable ear shells

Enjoy a comfortable fit and experience better bass performance thanks to the three-way adjustable ear shells that fit naturally around your ears.

40 mm speaker driver

The 40 mm speaker driver is made of a composite mylar material for a highly sensitive yet powerful element that delivers sound without audible distortion.

FM Wireless transmission

With high frequency FM wireless transmission, which can even pass through walls, you can even listen to your music when you're in another room.

Convenient automatic tuning

Convenient automatic tuning ensures best reception

Preformed soft ear-cushions

Preformed soft ear-cushions ensure a comfortable fit

Simple, convenient charging

Simple, convenient charging with a wireless dock

Bass boost feature

Bass boost feature reinforces bass reproduction



Issue date 2017-03-03

Version: 3.3.6

12 NC: 8670 000 79045
EAN: 69 23410 71056 4

© 2017 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com