

Philips CD Soundmachine with Dynamic Bass Boost

AZ1220

Enriched Base Sound

You take pleasure in the simple things in life and delight in convenience. The sleek and portable AZ1220 lets you indulge in the pleasures of enjoying your favorite music in enriched bass sound with the help of easy-to-use functions.

Enhanced bass performance

- Bass Reflex Speaker System delivers a powerful, deeper bass
- Dynamic Bass Boost for deep and dramatic sound
- 10.2 cm (4") full range speakers for powerful sound

Enjoy favorite music from three different sources

- Compatible with CD-Recordable and CD-ReWritable
- FM/MW tuner for radio enjoyment
- Autostop cassette deck

Easy to use

- CD to tape synchro-start recording
- Multi-functional LCD display
- Stereo headphone socket



Specifications

Sound

- Loudspeaker types: Bass Reflex Speaker System
- Output power (RMS): 2X1.2W
- Sound Enhancement: Dynamic Bass Boost
- Sound System: Stereo
- Speaker diameter: 4"
- Volume Control: rotary

Loudspeakers

- Built-in speakers: 2
- Finishing: Metal
- · Loudspeaker types: Loudspeakers

Audio Playback

- Cassette Deck Technology: Mechanical
- Playback Media: CD, CD-R, CD-RW
- Disc Playback Modes: Fast Forward/Backward, Next/Previous Track Search, Repeat Play, Shuffle Play
- Loader Type: Top
- Number of decks: 1
- Programmable Tracks: 20

Tuner/Reception/Transmission

Antenna: AM Antenna, FM Antenna

- Auto digital tuning: No
- Tuner Bands: FM, MW



Connectivity

Headphone: 3.5 mm

Convenience

- Display Digits: 4
- Display Type: LCD

Accessories

 Included accessories: AC Power Cord, User Manual, Warranty certificate

Dimensions

- Packaging dimensions (W x H x D):
- 470 x 210 x 290 mm • Product dimensions (W x H x D):
- 400 x 162 x 238 mm
- Weight: 2.9 kg
- Weight incl. Packaging: 3.7 kg

Power

- Battery type: LR14
- Battery voltage: 1.5 V
- Mains power
- Number of batteries: 6

AZ1220/01

Highlights

Bass Reflex Speaker System

Bass Reflex Speaker System delivers a deep bass experience from a compact loudspeaker box system. It differs from a conventional loudspeaker box system in the addition of a bass pipe that is acoustically aligned to the woofer to optimize the low frequency roll-off of the system. The result is deeper controlled bass and lower distortion. The system works by resonating the air mass in the bass pipe to vibrate like a conventional woofer. Combined with the response of the woofer, the system extends the overall low frequency sounds to create a whole new dimension of deep bass.

Dynamic Bass Boost

Dynamic Bass Boost maximizes your music enjoyment by emphasizing the bass content of the music throughout the range of volume settings from low to high – at the touch of a button! Bottomend bass frequencies usually get lost when the volume is set at a low level. To counteract this, Dynamic Bass Boost can be switched on to boost bass levels, so you can enjoy consistent sound even when you turn down the volume.

10.2 cm/4" full range speakers

10.2 cm (4") full range speakers for powerful sound

CD-R/RW Compatible

CD-Rewritable Compatible means that your audio set can play both CD-Recordable (CD-R) and CD-Rewritable (CD-RW) discs. CD-R discs are recordable once and can be played on any audio CD player while CD-RW discs can be recorded and rewritten multiple times and can only be played back on compatible audio CD players. The laser pick-up and CD decoder circuitry of CD-RW compatible players are specially designed to read the special audio CD-RW phase-change recording layer, ensuring you can always play your home-recorded discs on your audio CD system.

FM/MW tuner

FM/MW (AM) stereo tuner

Autostop cassette deck Autostop cassette deck

CD synchro-start recording CD to tape synchro-start recording

Multi-functional LCD display Multi-functional LCD display

Stereo headphone socket

Connect your own headphone for a more personal listening experience whenever you want it. You can enjoy your favorite music in great sound without disturbing others by connecting your headphones to the player.



Issue date 2015-01-22

© 2015 Koninklijke Philips N.V. All Rights reserved.

Version: 3.0.4

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips N.V. or their respective owners.

12 NC: 9073 101 01289 EAN: 87 10895 81652 6

www.philips.com