

Philips  
Multimedia Speaker 2.0

Bulk Version

MMS121



## Great sound from compact speakers

### Convenient multimedia enjoyment

The fun way to enjoy authentic stereo sound with your music, Internet and multimedia PC applications is to add the compact MMS121 Harmonic Pulse speaker system with unbelievable bass performance for their size.

#### Experience true multimedia

- Compatible with music, games, film & internet audio sources
- Easy to connect to either a PC or a laptop

#### Hear every detail

- Bass Reflex speakers deliver a powerful, deeper bass
- Dynamic Bass Boost for deep and dramatic sound

#### Easy to use

- Labelled and color-coded connectors get you going in minutes
- Headphone jack for better personal music enjoyment
- Magnetic Shielding eliminates computer screen distortion

**PHILIPS**  
sense and simplicity

## Specifications

### Sound

- **Bass enhancement:** Digital Bass Boost
- **Music Power:** 3 W
- **Output power (RMS):** 2 x 0.75W
- **Volume Control:** Analogue Volume Control
- **Wires:** Fixed Wires

### Loudspeakers

- **Loudspeaker Enhancement:** Magnetic Shielded LSB

### Connectivity

- **Cable length:** 2 m
- **Connector:** 3.5 mm stereo
- **Headphone:** 3.5 mm

### Convenience

- Power on indication

### Packaging content

- **Number of satellites:** 2
- Quick installation guide

### Packaging Data

- **I2NC:** 908210002913
- **EAN/UPC/GTIN:** 8710895815970
- **Gross weight:** 1.08 kg
- **Height:** 180 mm
- **Length:** 200 mm
- **Width:** 115 mm
- **Quantity:** 1
- **Tare weight:** 0.12 kg

### Outer Carton

- **Quantity:** 8
- **EAN/UPC/GTIN:** 8710895816076
- **Tare weight:** 0.76 kg
- **Gross weight:** 9.4 kg
- **Length:** 415 mm
- **Width:** 250 mm
- **Height:** 380 mm
- **I2NC:** 90821002913

## Product highlights

### Music, games, films, internet

All types of music, games, films and internet audio sources can be played, so no matter what you want to hear, we make your multimedia experiences sound more involving than ever.

### For PC or Laptop

Can be connected to either a PC or a laptop

### Bass Reflex Speaker System

Bass Reflex Speaker System delivers a deep bass experience from a compact loudspeaker box system. It differs from a conventional loudspeaker box system in the addition of a bass pipe that is acoustically aligned to the woofer to optimize the low frequency roll-off of the system. The result is deeper controlled bass and lower distortion. The system works by resonating the air mass in the bass pipe to vibrate like a conventional woofer. Combined with the response of the woofer, the system extends the overall low frequency sounds to create a whole new dimension of deep bass.

### Dynamic Bass Boost

Dynamic Bass Boost maximizes your music enjoyment by emphasizing the bass content of the music throughout the range of volume settings - from low to high - at the touch of a button! Bottom-end bass frequencies usually get lost when the volume is set at a low level. To counteract this, Dynamic Bass Boost can be switched on to boost bass levels, so you can enjoy consistent sound even when you turn down the volume.

### Quick set-up

Color-coded cables, clear labelling and easy to understand documentation mean you'll be up and running in minutes

### Headphone jack

### Magnetic Shielding

Because the powerful magnets in speaker drivers are magnetically shielded, there's no danger of image distortion or damage when placed close to your PC monitor screen.

