Premium quality surround sound

The ultimate 5.1 channel experience

The powerful wooden sub-woofer and five satellite speakers let you bring Dolby Digital[™] and EAX[™] surround sound to your music, games, films and Internet on a PC or laptop. Faithfully reproducing the full range of audio frequencies from deep bass to crystal clear high notes with the minimum of distortion, you'll hear the difference.

Your computer never sounded so good

• Home audio quality on the PC

Experience true multimedia

- Music, games, films, internet
- 5.1 channel playback

Hear every detail

- Subwoofer + satellite speakers
- Open-face speakers
- Wooden subwoofer
- Bass Reflex Speaker System
- Digital Dynamic Bass Boost

Easy to use

- Quick set-up
- Magnetic Shielding











Commercial Specifications

Sound

- Bass enhancement • Output power (RMS)
- Total Music Power
- Volume Control
- Wires

Loudspeakers

- Loudspeaker Enhancement
- Satellite speaker freq range
- Subwoofer freq range

Connectivity

- Connector
- Cable length Power

Convenience

•	Power	on	indication	

Accessories

•	Included	Acces	sorie

Power

•	Power	LED	indicator
---	-------	-----	-----------

Digital Bass boost $5 \times 10 + 30 W$ 160 W Analogue Volume Control Fixed Wires

Magnetic Shielded LSB 180-20000 Hz 20-180 Hz

3 x 3.5 mm

AC Adaptor 18V

Quick install guide

2 m

yes

Blue

- - Width

Packaging Data • 12NC

- EAN Ouantity
- Length
- Width Height

Outer Carton

- EAN Quantity
- Length
- Height

9082 100 02957 87 10895 81921 3 46.1 cm 24.6 cm

87 10895 83027 0

34 cm

44 cm

37.9 cm

49.4 cm

Music, games, films, internet

Home audio quality on the PC

All types of music, games, films and internet audio sources can be played, so no matter what you want to hear, we make your multimedia experiences sound more involving than ever.

Philips has used over 75 years experience at the

leading edge of audio to create PC audio products

with the same performance as our award-winning

5.1 channel playback

5.1 channel sound for reproduction of Dolby Digital® and EAX® sound sources.

Subwoofer + satellite speakers

The audio system is separated into a subwoofer that is optimized to reproduce bass frequencies and satellite speakers that are optimsed for mid- and high-range frequencies. The result is a system that powerfully reproduces the full range of audio frequencies from deep bass to crystal clear high notes with the minimum of distortion.

Open-face speakers

To hear every detail in your audio, aerodynamic protectors are used instead of a cloth or metal cover. This not only prevents damage to the speaker, but also enables maximum sound to be produced with minimum distortion.

Wooden subwoofer

The housing of the subwoofer is made from wood, giving it superior stability and acoustical performance.

Bass Reflex Speaker System

Bass Reflex Speaker System delivers a deep bass experience from a compact loudspeaker box system. It differs from a conventional loudspeaker box system in the addition of a bass pipe that is acoustically aligned to the woofer to optimize the low frequency roll-off of the system. The result is deeper controlled bass and lower distortion. The system works by resonating the air mass in the bass pipe to vibrate like a conventional woofer. Combined with the response of the woofer, the system extends the overall low frequency sounds to create a whole new dimension of deep bass.

Digital Dynamic Bass Boost

Digital Dynamic Bass Boost is an intelligent bass booster that delivers maximum bass enhancement at high volumes without sound distortion and at low volumes without compromising on bottom-end bass frequencies. Technologically advanced electronics constantly monitor volume and bass levels, precisely calibrating both to prevent sound distortion, thus producing optimized bass. Digital Dynamic Bass Boost enables the enjoyment of superb bass performance - regardless of the chosen volume level.

Quick set-up

Color-coded cables, clear labelling and easy to understand documentation mean you'll be up and running in minutes.

Magnetic Shielding Because the powerful magnets in speaker drivers are magnetically shielded, there's no danger of image distortion or damage when placed close to your PC monitor screen.

Date of issue: March 2004

Specifications are subject to change without notice Trademarks owned by Royal Philips Electronics 2004 © Royal Philips Electronics - All rights reserved

www.philips.com/pcstuff





MMS460

Product Highlights

home audio systems.