



Philips
DVD micro music system

with 30-pin connector

for iPod/iPhone/iPad
DVD, CD, USB, FM
120W, Bass radiator

DCD3020



Relax with great music

Obsessed with sound

Listen to music from your iPod/iPhone/iPad - simply by docking it as it is, without having to remove its case. The Philips DVD micro music system delivers powerful bass, thanks to wOOx technology, and plays DVDs, DivX files, CDs and MP3-CDs

Enjoy your favorite movies and music

- Play DVD, DivX®, (S)VCD, MP3-CD, WMA-CD, CD(RW) & Picture CD
- Dolby Digital for ultimate movie experience
- Play and charge your iPod/iPhone/iPad
- USB Direct for MP3/WMA music playback

Enrich your sound experience

- wOOx™ loudspeaker Technology for deep and powerful bass
- Digital Sound Control for optimized music style settings
- 120W RMS total output power

Easy to use

- FM digital tuning to preset up to 20 stations
- Motorized CD loader for convenience access
- Wake up and sleep timer functions

PHILIPS

DVD micro music system
with 30-pin connector for iPod/iPhone/iPad, DVD, CD, USB, FM, 120W, Bass radiator

DCD3020/58

Highlights

Play & charge iPod/iPhone/iPad



Enjoy your favorite MP3 music while charging your iPod/iPhone/iPad! The dock lets you connect your portable device directly to the Philips system so you can listen to your favorite music in superb sound. It also charges your iPod/iPhone/iPad while it plays so you can enjoy your music and not have to worry about your portable player battery running out. The system automatically charges your portable device while it is docked.

Play DVD, DivX & MP3/WMA-CD



The Philips player is compatible with most DVD and CD discs available in the market. DVD, DivX®, (S)VCD, MP3/WMA-CD, CD(RW) and Picture CD - all of them can play on the player. SVCD stands for "Super VideoCD". The quality of a SVCD is much better than a VCD, especially much more sharpen picture than a VCD because of the

higher resolution. With DivX® support, you are able to enjoy DivX® encoded videos. The DivX media format is an MPEG4-based video compression technology that enables you to save large files like movies, trailers and music videos on media like CD-R/RW, and DVD recordable discs.

USB Direct



With the USB Direct mode, simply plug in your USB device to the USB port on your Philips device and your digital music will be played directly from the Philips device.

wOOx™ Technology



wOOx technology is a revolutionary loudspeaker concept that allows you to hear and feel profoundly deep bass that is richer than any other audio system. Special speaker drivers work in harmony with the wOOx bass radiator, and precise tuning between the main

driver and the tweeter ensures smooth transitions from low-mid to high frequencies. Dual suspension and a totally symmetrical sandwich construction deliver low and precise base without noticeable distortion. wOOx produces exceptionally deep and dynamic bass by using the speaker box full volume to truly magnify the impact of the music.

Digital Sound Control



Digital Sound Control offers you a choice of pre-set Jazz, Rock, Pop and Classic controls you can use to optimise the frequency ranges for different musical styles. Each mode uses graphic equalizing technology to automatically adjust the sound balance and enhance the most important sound frequencies in your chosen music style. Ultimately, Digital Sound Control makes it easy for you get the most out of your music by precisely adjusting the sound balance to match the type of music you are playing.



Specifications

Sound

- Output Power: 2 x 60W
- Sound Enhancement: Digital Sound Control, Dynamic Bass Boost
- Sound System: Dolby Digital

Loudspeakers

- Main Speaker: Dome tweeter, Dual woofer, wOOx Bass Radiator

Video Playback

- Playback Media: DivX, DivX Ultra, DVD-Video, Picture CD, Video CD/SVCD, DVD+R/+RW, DVD-R/-RW
- Disc Playback Modes: A-B Repeat, Angle, PBC, Slow Motion, Zoom, Parental control, Disc Menu, Fast Backward, Fast Forward, OSD, Resume Playback from Stop
- DVD Region.: 5
- Video Enhancement: Progressive Scan

Audio Playback

- Playback Media: WMA-CD, MP3-CD, CD, CD-R, CD-RW
- Disc Playback Modes: 20-Track Programmable, Repeat/one/all/program, Shuffle Play, Fast Forward/Backward, Next/Previous Track Search
- Loader Type: Motorised, Tray
- USB Direct Modes: Fast Backward/Fast Forward, Play/Pause, Previous/Next, Program Play, Repeat, Shuffle, Stop
- ID3-tag support

Still Picture Playback

- Picture Compression Format: JPEG
- Picture Enhancement: Slideshow with MP3 playback
- Playback Media: Picture CD, CD-R/RW, DVD+R/+RW

Tuner/Reception/Transmission

- Tuner Bands: FM Stereo
- Auto digital tuning

- Tuner Enhancements: Auto Store
- Station presets: 20

Connectivity

- Video Output - Analog: Composite CVBS (yellow cinch), Component Y Pb Pr (cinch)
- Audio Connections: Analogue Audio In (L/R), Analogue Audio Out (L/R)
- USB: USB host
- MP3 Link: 3.5mm stereo line in
- Headphone: 3.5 mm
- Other connections: FM Antenna

Convenience

- Alarms: CD Alarm, Sleep timer, Radio Alarm, USB alarm
- Clock: On main display
- OSD Languages: UK-English, Polish, Czech, Turkish, Romanian, Hungarian, Russian, Danish, Norwegian, Swedish, Finnish, Greek, French, German, Dutch, Italian, Spanish, Portuguese
- Display Type: VFD display
- Indications: DIM mode

Accessories

- Included accessories: Composite video cable (Y), AC Power Cord, FM antenna, MP3 Link Cable
- Remote control: 41 key
- Quick start guide: .
- User Manual: English, Swedish, Danish, Finnish, Polish, Czech, Slavok, Hungarian
- Warranty: World Wide Guarantee booklet

Dimensions

- Set dimensions (W x H x D): 230 x 141 x 230 mm
- Main speaker dimensions (W x H x D): 139 x 304 x 230 mm
- Packaging dimensions (W x H x D): 512 x 346 x 276 mm
- Weight incl. Packaging: 8.6 kg

Power

- Power supply: 220-240V, 50Hz



Issue date 2014-06-12

Version: 1.0.5

12 NC: 8670 000 98517
EAN: 87 12581 67061 0

© 2014 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com