

Philips Multimedia Speakers 2.0

MMS223

PC speakers, clock and FM radio in one

Time for multimedia stereo

This active 12-watt (MPO) MMS223 stereo speaker system not only brings you quality stereo but also incorporates a stylish LCD clock and FM radio that you can also use without the PC.

Your computer never sounded so good

- · Enjoy PC audio with the quality of a home audio system
- Over 75 years of audio experience

Experience true multimedia

- · Compatible with music, games, film & internet audio sources
- · Built-in FM radio and clock for use even without a PC
- Easy to connect to either a PC or a laptop

Hear every detail

- Bass Reflex Speaker System delivers a powerful, deeper bass
- · Digital Dynamic Bass Boost for optimized bass at any volume

Easy to use

- · Labelled and color-coded connectors get you going in minutes
- Headphone jack for better personal music enjoyment
- Magnetic Shielding eliminates computer screen distortion



Specifications

Sound

- Bass enhancement: Digital Bass Boost
- Frequency response: 120-20000 Hz
- Output power (RMS): 2 x 3W
- Music Power: 12 W
- Volume Control: Analogue Volume Control
- Wires: Fixed Wires

Loudspeakers

Loudspeaker Enhancement: Magnetic Shielded LSB



Connectivity

- Headphone: 3.5 mmPower: AC Adaptor 12V
- Power: AC Adaptor 12v

Convenience

Power on indication

Accessories

Included accessories: Quick install guide

MMS223/00S

Highlights

Home audio quality on the PC

Philips has used over 75 years experience at the leading edge of audio to create PC audio products with the same performance as our award-winning home audio systems.

75 Years of audio experience

Philips invented the CD, lead the team that wrote the USB audio specification and has produced millions of audio systems, home cinema sets and TV's over many decades. As a leader in audio innovation, you can trust Philips to make PC sound systems of the highest sound quality.

Music, games, films, internet

All types of music, games, films and internet audio sources can be played, so no matter what you want to hear, we make your multimedia experiences sound more involving than ever.

Built-in FM radio and clock

Contains an FM radio that works even when not connected to the PC and a convenient LCD clock

For PC or Laptop

Can be connected to either a PC or a laptop

Bass Reflex Speaker System

Bass Reflex Speaker System delivers a deep bass experience from a compact loudspeaker box system. It differs from a conventional loudspeaker box system in the addition of a bass pipe that is acoustically aligned to the woofer to optimize the low frequency roll-off of the system. The result is deeper controlled bass and lower distortion. The system works by resonating the air mass in the bass pipe to vibrate like a conventional woofer. Combined with the response of the woofer, the system extends the overall low frequency sounds to create a whole new dimension of deep bass.

Digital Dynamic Bass Boost

Digital Dynamic Bass Boost is an intelligent bass booster that delivers maximum bass enhancement at high volumes without sound distortion and at low volumes without compromising on bottom-end bass frequencies. Technologically advanced electronics constantly monitor volume and bass levels, precisely calibrating both to prevent sound distortion, thus producing optimized bass. Digital Dynamic Bass Boost enables the enjoyment of superb bass performance - regardless of the chosen volume level.

Quick set-up

Color-coded cables, clear labelling and easy to understand documentation mean you'll be up and running in minutes

Headphone jack

Headphone jack for better personal music enjoyment

Magnetic Shielding

Because the powerful magnets in speaker drivers are magnetically shielded, there"s no danger of image distortion or damage when placed close to your PC monitor screen.



Issue date 2014-02-06

© 2014 Koninklijke Philips N.V. All Rights reserved.

Version: 4.0.5

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips N.V. or their respective owners.

12 NC: 9082 100 02935 EAN: 87 10895 81681 6

www.philips.com