

Philips
Micro Hi-Fi System

MCI08C



Compact audio system to match your lifestyle

Great sound in a compact, elegant design! The MCI08C delivers dynamic sound performance and the essential functionalities that will let you enjoy music just the way you like it.

Enrich your sound experience

- Plays CD, CD-R and CD-RW discs
- Dynamic Bass Boost for deep and dramatic bass
- Convenient line-in jack for portable music playback
- 2x2W RMS total output power

Wake up to CD or radio tunes

- Wake-Up and Sleep Timer
- Stereo tuning with digital readout

Fits any space, any lifestyle

- Compact design

PHILIPS
sense and simplicity

Specifications

Sound

- **Output Power:** 2x2W RMS / 2x4W music power
- **Volume Control:** Volume Control up/down
- **Sound Enhancement:** Dynamic Bass Boost

Loudspeakers

- **Main Speaker:** 3.5" woofer

Audio Playback

- **Playback Media:** CD, CD-R, CD-RW
- **Disc Playback Modes:** 20-Track Programmable, Repeat/one/all/program, Shuffle Play
- **Loader Type:** Top

Tuner/Reception/Transmission

- **Tuner Bands:** FM Stereo, MW

Connectivity

- **Headphone:** 3.5 mm
- **Other connections:** FM fixed pigtail antenna, MW

Antenna

- **Aux in:** Line-in, 3.5 mm

Convenience

- **Alarms:** Sleep timer, CD Alarm, Radio Alarm
- **Clock:** On main display
- **Display Type:** LCD
- **Backlight colour:** White

Accessories

- **Remote control:** 17-key with battery
- **Included Accessories:** FM/MW Antenna

Dimensions

- **Set dimensions (W x H x D):**
150 x 150 x 200 mm
- **Main speaker dimensions (W x H x D):**
150 x 150 x 200 mm
- **Packaging dimensions (W x H x D):**
286 x 525 x 200 mm
- **Weight incl. Packaging:** 4.28 kg

Product highlights

Dynamic Bass Boost

Dynamic Bass Boost maximises your music enjoyment by emphasising the bass content of the music throughout the range of volume settings - from low to high - at the touch of a button! Bottom-end bass frequencies usually get lost when the volume is set at a low level. To counteract this, Dynamic Bass Boost can be switched on to boost bass levels, so you can enjoy consistent sound even when you turn down the volume.



Issue date 2009-02-12

Version: 1.0.2

12 NC: 8670 000 33916
EAN: 87 12581 36366 6

© 2009 Koninklijke Philips Electronics N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips
Electronics N.V. or their respective owners.

www.philips.com