



Philips
Over-ear wireless
headphones

Noise Cancelling Pro

Clear calls. Attachable mic
Bluetooth multipoint
Up to 55 hours of play time



TAH8507BK

Clear calls. Great sound.

Whether in the office, home or commuting in between, these over-ear, wireless headphones with attachable mic are made for business. Advanced noise cancellation removes environmental distractions, and your calls will be clear for meetings too!

Great sound. Sleek looks

- Sleek design with Noise Cancelling Pro
- Great audio from 40 mm drivers
- Crystal-clear vocal clarity
- Up to 55 hours of play time*

Simple connection. Built for business

- Bluetooth multipoint. Connect to two devices at once
- Attachable boom mic for amazing call clarity
- Plug-in Bluetooth dongle for quick connectivity
- Busy mode lights light up to show others you are on a call

Made with you in mind

- Philips Headphones app. Custom sound and more
- Touch controls. Swipe, tap and press to control
- Lightweight and comfortable to wear
- Smart-looking case keeps the headphones safe

PHILIPS

Over-ear wireless headphones

Noise Cancelling Pro Clear calls. Attachable mic, Bluetooth multipoint, Up to 55 hours of play time

TAH8507BK/00

Highlights

Noise Cancelling Pro



These lightweight, wireless headphones look great and let you focus on what you want to hear. Advanced noise cancellation filters out unwanted sounds from the outside world. Awareness mode lets you bring the world back in when you need to.

Great sound



Perfectly tuned 40 mm drivers deliver great detail and bass for every song or podcast. Use the included audio cable to plug in for hi-res audio from your favourite streaming service. When you're done, the hard case keeps the headphones safe.

Bluetooth multipoint



Watch a movie on your tablet. Take a call on your phone. With Bluetooth multipoint connectivity, you can connect up to two smart devices to the headphones simultaneously. Switch between them as you need!

Up to 55 hours of play time*



With noise cancelling off, you get up to 55 hours to enjoy your tunes, podcasts and more. With noise cancelling on, it's up to 45 hours. A full charge takes two hours and, for a boost, you get an extra four hours with a quick 15-minute charge.

Attachable boom mic



These fantastic headphones feature an innovative, attachable boom microphone.

When you need to make a call, simply attach the mic to achieve crystal-clear vocal clarity. When you're done, detach the mic and carry on listening!

Plug-in BT dongle



Get a stable connection to your smartphone and laptop at the same time. Use your headphones to pick up calls on either and switch between devices as you need. Simply plug the included dongle into your computer's USB-C socket or connect to USB-A sockets via the included adapter.

Philips Headphones app



The Philips Headphones app puts you in charge of the music you're listening to. Adjust levels yourself or choose from preset sound styles. You can also use the app to switch between preset noise-cancellation modes.



Over-ear wireless headphones

Noise Cancelling Pro Clear calls. Attachable mic, Bluetooth multipoint, Up to 55 hours of play time

TAH8507BK/00

Specifications

Sound

- Impedance: 32 Ohm
- Speaker diameter: 40 mm
- Sensitivity: 96 dB (1 kHz)
- Frequency range: 7 - 40,000 Hz
- Maximum power input: 30 mW
- Hi-Res Audio
- Driver type: Dynamic

ANC features

- ANC (Active Noise Canceling)
- ANC technology: Hybrid
- Microphone for ANC: 4 mic
- Awareness mode

Telecommunication

- Microphone for call: 1 mic

Connectivity

- Type of wireless transmission: Bluetooth
- Wireless
- Bluetooth version: 5.0
- Supported codec: AAC, SBC
- Maximum range: Up to 10 m
- Bluetooth profiles: A2DP, AVRCP, HFP
- Multipoint connection
- Detachable cable
- Headphone socket: 2.5 mm

Convenience

- Philips Headphones app support
- Firmware updates possible
- Type of controls: Touch
- Volume control
- Automatic power off

Design

- Colour: Black
- Foldable design: Flat/Inward
- Wearing style: Headband
- Ear coupling material: Synthetic leather
- Ear fitting: Over-ear
- Earcup type: Closed-back

Power

- Music play time (ANC off): 55 hr*
- Music play time (ANC on): 45 hr*
- Battery type (Headphones): Lithium Polymer (built-in)

- Battery capacity (Headphones): 800 mAh
- Charging time: 2 hr
- Fast charging time: 15 mins for 4 hrs
- Number of batteries: 1 pcs
- Battery weight (Total): 14.936 g
- Rechargeable

Voice assistant

- Voice assistant support
- Voice assistant activation: Manual
- Voice assistant compatible: Apple Siri, Google Assistant

Accessories

- Audio cable: 2.5-3.5 mm stereo cable, L=1.2 m
- Charging cable: USB-C cable, 500 mm
- Included adapters: Aeroplane adapter, Bluetooth dongle
- Others: 1 pcs hard carrying case, 1 pcs attachable boom mic
- Quick Start Guide

Outer Carton

- Number of consumer packages: 3
- GTIN: 1 48 95229 12630 2
- Gross weight: 2.231 kg
- Outer carton (L x W x H): 23.1 x 21.1 x 26 cm
- Net weight: 1.584 kg
- Tare weight: 0.647 kg

Packaging dimensions

- Packaging type: Box
- Number of products included: 1
- Type of shelf placement: Hanging
- EAN: 48 95229 12630 5
- Packaging dimensions (W x H x D): 18.8 x 25.1 x 6.8 cm
- Gross weight: 0.667 kg
- Net weight: 0.528 kg
- Tare weight: 0.139 kg

Product dimensions

- Product dimensions (W x H x D): 18.5 x 20.5 x 4.5 cm
- Weight: 0.282 kg

UPC

- UPC: 8 40063 20231 3



Issue date 2023-11-13

Version: 6.0.3

12 NC: 8670 001 82076
EAN: 48 95229 12630 5

© 2023 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com

* Battery life of play time is approximate and may vary depending on application condition.