

Philips
Digital PhotoFrame

20.3cm/8"

Multimedia
4:3 frame ratio

SPF4208



"...this is where he proposed!"

Showcase those unforgettable moments with this Photoframe. This frame is designed for maximum ease of use as well as eco-friendliness. Rest assured that while you are enjoying your photos, you made the right choice for the environment.

Top quality display for amazing viewing experience

- 4:3 aspect ratio for optimal distortion-free display
- imagen Pro for sharp, vibrant and natural skin colors
- Add new glow to old memories with RadiantColor

Simple intuitive operation and great convenience

- Automatic slideshow from USB or memory card
- Auto photo orientation to fit portrait or landscape modes
- Have fun with collages: display multiple photos in one view

Environmentally friendly green design

- Eco-friendly Photoframe
- Auto on/off display at pre-set times for power saving



asimpleswitch.com



asimpleswitch.com

PHILIPS

Specifications

Picture/Display

- Viewing angle: @ C/R > 10, 120° (H) / 100° (V)
- Lifetime, to 50% brightness: 20000 hr
- Aspect ratio: 4:3
- Panel resolution: 800 x 600
- Brightness: 250 cd/m²
- Contrast ratio (typical): 300:1

Connectivity

- USB: USB 2.0 Host, USB 2.0 Slave

Storage Media

- Built-in memory (RAM): 512MB (for 500 HD photos)
- USB: USB flash drive
- Memory Card Types: Secure Digital (SD), Secure Digital (SDHC), Multimedia Card, xD card, Memory Stick, Memory Stick Pro, Memory Stick Duo, Memory Stick Pro Duo

Convenience

- Photo format supported: JPEG photo, Up to 10MB JPEG files, Up to 20 Megapixels
- Video format supported: MotionJPEG
- Background Music supported: MP3
- Card Reader: Built-in (1x)
- Placement: Landscape, Portrait, Photo auto orientation
- Buttons and controls: Power button, 3 buttons, 4-way navigation key and enter
- Playback mode: Full screen browse, Slideshow, Thumbnail browse
- Album management: Create, Delete, Edit, Rename
- Photo edit: Copy, Delete, Rotate, Zoom & crop
- Slideshow setting: Random, Sequential, Transition effect, Collage (multiple pictures)
- Setup function: Slideshow, Clock display enable/disable, Event reminder with snooze
- Regulatory approvals: CE, GOST, Switzerland
- Other convenience: Kensington lock compatible

Accessories

- Included accessories: AC-DC Adapter, Quick start guide, User manual on CD-ROM
- User Manual: Arabic, Czech, Danish/Norwegian, Dutch, English, Finnish, French, German, Greek, Italian, Malay, Polish, Portuguese, Russian, Simplified Chinese, Spanish, Swedish, Traditional Chinese, Turkish

Dimensions

- Set dimensions with stand (W x H x D): 222.6 x 182.2 x 33.2 mm
- Weight: 0.34 kg
- Temperature range (operation): 0°C to 40°C
- Temperature range (storage): -10°C to 60°C

Power

- Power supply: 100-240VAC, 50/60Hz
- Power consumption: (System on) 5.5 W
- Power mode supported: AC powered
- DC output Ampère: 1 A
- DC output Volt: 9 V

Packaging dimensions

- EAN: 87 12581 50307 9
- Number of products included: 1
- Packaging type: Carton
- Packaging dimensions (W x H x D): 25 x 21 x 9.5 cm
- Gross weight: 1.03 kg
- Nett weight: 0.78 kg
- Tare weight: 0.25 kg

Outer Carton

- GTIN: 1 87 12581 50307 6
- Number of consumer packagings: 2
- Gross weight: 2.3 kg
- Outer carton (L x W x H): 26 x 20 x 21.9 cm
- Nett weight: 1.56 kg
- Tare weight: 0.74 kg



Highlights

imagen Pro for vibrant colors

The unique Philips imagen enhancement technology automatically analyzes your photos to correct color and adjust for optimal contrast. imagen Pro is a more advanced image enhancement which includes the 3 essential elements from imagen to have more color accuracy, color depth and smart contrast. On top of these, imagen Pro offers enhanced skin color, sharper images and flicker-free photo viewing which is very important for still pictures.

4:3 perfect frame ratio

Philips digital PhotoFrame ensures your photo to be displayed in 4:3 ratio for the best viewing experience.

Automatic slideshow

Automatic slideshows start from any USB drive or memory card for all those moments you don't want to spend time copying photos to your PhotoFrame.

RadiantColor

RadiantColor is an exclusive Philips technology for displaying smaller photos in the optimal 4:3 ratio by extending the color on the edges of a less-than-full-screen photo to the sides of the screen, eliminating black bars and aspect ratio distortion.

Eco-friendly Photoframe

Philips PhotoFrame are designed and produced according to our EcoDesign principles aimed at minimizing overall environmental impact, through lower power consumption, removal of hazardous substances, lower weight, more efficient packaging and better recyclability.

Auto orientation

Automatic landscape/portrait recognition employs a sensor that recognizes PhotoFrame orientation and displays each photo in its proper mode.

Multiple-photo collage effect

It's a slideshow effect to show photos in collage form that automatically and randomly compiles different photos together to avoid unattractive borders that may result from photos which are smaller than the screen size.

Auto on/off display

A timer turns PhotoFrame on and off at the hours you select, reducing energy consumption for the sake of our environment saving up to one third of your PhotoFrame energy costs.



Issue date 2014-02-10

Version: 2.0.5

12 NC: 8670 000 55928
EAN: 87 12581 50307 9

© 2014 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com