

Snap & Share

All-in-one image communication

The ThumbCam is the perfect solution for video-conferencing on-line with your laptop, taking 1.3 megapixel snapshots, recording a full ten minutes of video or storing up to 128 MB of your data. Use it anytime! And with simple installation, you will be up and running with high picture quality image communication in a matter of seconds.



Stay in touch by sharing your experiences

- Real-time video chatting
- Video mails via Internet
- 128 MB removable memory drive

High picture quality

- 1.3 MP resolution snapshots
- VGA @ 15 fps video quality

Easy to use

- Photo Manager
- LinkExpress
- VLounge control panel
- Built-in digital microphone



PHILIPS

Commercial Specifications

Picture

- Sensor 1/2" 1.3 MP CMOS
- Max. photo resolution 1.3 MP (1280 x 1024)
- Max. video resolution VGA (640 x 480)
- Max. frames per second as a webcam VGA (640x480) up to 15 fps or CIF (320x240) up to 30 fps
- Max. frames per second as a digital camera CIF (320x240) up to 15 fps
- Image format Compressed JPEG
- Video format AVI
- Lens Fixed focus, f=8.7mm
- Focus range 1.5 m to infinity
- Exposure Automatic
- Viewfinder Optical
- LCD screen 3 Digit status LCD
- Microphone Built-in in camera
- Self-timer 10 s
- Auto power off After 60 s

Accessories

- Laptop clamp with USB 1.1 cable attached
- USB cover
- Neck cord
- CD-ROM with software and PDF user manual
- Quick installation guide

Connections

- PC Connection USB 1.1

Power supply

- Via USB connection
- Built-in rechargeable Li-Polymer battery

Software

- ThumbCam driver for Windows
- LinkExpress for automatic image upload from FunCam to PC
- Philips Photo Manager 1.0 for archiving, editing, printing and emailing Snapshots & Video clips
- Philips VRecord for recording video clips with audio when using the FunCam as a webcam
- Acrobat reader 6.0 for reading PDF user manual
- Netmeeting 3.0 for video chatting over the internet
- Works with MSN Messenger and Yahoo! Messenger for video chatting over the internet

PC system requirements

- Operating system Windows 98SE, 2000, ME, XP
- PC system Pentium II or AMD K6-11 or above, 32 MB RAM, 100 MB free HDD, CD or DVD-ROM drive, 1 free USB port, Audio playback capability, Internet connection for video chatting
- Caution PC systems that were upgraded from Windows 95 to Windows 98 may not have USB compatibility

Packaging information

- 12NC 9082 100 02991
- EAN code 87 10895 82753 9
- ThumbCam with USB cover (mm) 114 (H) x 35 (W) x 23.5 (D)
- ThumbCam with laptop clamp (mm) 163 (H) x 35 (W) x 23.5 (D)
- Weight ThumbCam with USB cover 68 g

Product Highlights

Video chatting

On-line video chatting (communication) over a distance.

Video mails via Internet

Record a personal video clip and send it as an e-mail attachment to a friend, family or business contact.

128 MB removable memory drive

The removable memory drive allows you to temporarily store files in an external memory medium and to share them between PC off-line.

1.3 MP resolution snapshots

An image taken at 1.3-megapixels resolution creates an image of 1280 by 1024 pixels, a good size for web pages and e-mails.

VGA @ 15 fps video quality

VGA (640x480) resolution at 15 frames per second video quality.

Photo Manager

Philips Photo Manager 1.0 is an easy-to-use software application for archiving, editing, printing and e-mailing your snapshots and video clips.

LinkExpress

With one button click LinkExpress enables you to transfer all your new images from a digital camera to your PC.

VLounge control panel

Vlounge control panel for quickly access your PC camera applications.

Built-in digital microphone

The built-in digital microphone allows you to record dialog or to add sound to a video clip recording.

