

PHILIPS

USB power bank

30,000 mAh

USB A and USB C charging ports

QC 3.0 and PD

Black

DLP1930CB



Powerful power bank

with a portable back-up power pack

Have power wherever and whenever you need it. Large 30,000 mAh capacity for up to more than 1 full charge. 3 USB ports with USB-A and USB-C. Fast charge your device with USB-C PD 3.0 Max 20 W or a USB-A port with QC 3.0 Max 18 W output.

Superior Charging Design

- Smart protection against overheating, overvoltage and overcurrent
- Quick Charge technology to optimise charging speed
- 50% charge in 30 minutes
- Charging using USB-C Programmable Power Supply (PPS)
- 3 USB ports charge three devices simultaneously

Confirm operation at a glance

- LCD display for power indication

Portable power

- Recharge your devices multiple times on the go
- Works anywhere - great when you're not near a power source
- Fast charge with USB-C PD 3.0 20 W or USB-A with QC 3.0 18 W

Highlights

LCD display for power status

LCD display for power indication

Programmable Power Supply PPS

PPS (Programmable Power Supply) is a standard for fast charging technology for USB-C devices. This technology adjusts the voltage and current in real time, depending on a device's charging status, feeding it with maximum power. A smart way to safely reduce charging time.



Smart Protection

Smart protection against overheating, overvoltage and overcurrent

Fast charge USB-C or USB-A

Fast charge your device with USB-C PD 3.0 Max 20 W or a USB-A port with QC 3.0 Max 18 W output

Specifications

Outer Carton

Length: 39 cm
Number of consumer packages: 21
Length: 15.4 inch
Width: 35 cm
Gross weight: 15.96 kg
Height: 23 cm
GTIN: 1 48 95229 13427 7
Width: 13.8 inch
Height: 9.1 inch
Net weight: 12.978 kg
Gross weight: 35.185 lb
Net weight: 28.611 lb
Tare weight: 2.982 kg
Tare weight: 6.574 lb

Inner Carton

Length: 36.5 cm
Number of consumer packages: 7
Length: 14.4 inch
Width: 11 cm
Height: 20.5 cm
Width: 4.3 inch
Height: 8.1 inch
GTIN: 2 48 95229 13427 4

Power

Battery Capacity: 30,000 mAh 111 Wh
Power input: USB C\Micro USB 5 V/2 A
Output: USB & Type-C 5 V/3 A

Packaging dimensions

Height: 19.5 cm
Width: 9.5 cm
Depth: 5 cm
Height: 7.7 inch
Number of products included: 1
EAN: 48 95229 13427 0
Width: 3.7 inch
Gross weight: 0.698 kg
Depth: 2.0 inch
Net weight: 0.618 kg
Gross weight: 1.539 lb
Net weight: 1.362 lb
Tare weight: 0.08 kg
Tare weight: 0.176 lb

Product dimensions

Height: 14.2 cm
Width: 7.2 cm
Depth: 4.09 cm
Width: 2.8 inch
Height: 5.6 inch
Depth: 1.6 inch
Weight: 0.618 kg
Weight: 1.362 lb

Accessories

Cables: USB-C cable
User Manual: User Manual

