

Philips  
DVD Micro Theater

DivX playback  
USB Direct

MCD149



## Turn Any Rooms into Theater

You're in touch with the latest and the coolest - now get a load of the hot 2-in-1 Micro Hi-Fi with DVD, WMA-CD and MP3-CD playback! Relax to your fave movies and music. Home entertainment will never be the same again!

### Enjoy your favorite movies, photos and music

- Play DVD, DivX®, (S)VCD, MP3-CD, WMA-CD, CD(RW) & Picture CD
- Enjoy MP3/WMA music directly from your portable USB drives
- Dolby Digital for ultimate movie experience
- Progressive Scan component video for optimized image quality

### Enrich your sound experience

- Digital Sound Control for optimized music style settings
- Dynamic Bass Boost for deep and dramatic sound
- Aux-in to enhance TV sound
- 200W RMS total output power (2.1 system)

### Start the day your way

- Wake up and sleep timer functions
- Digital tuning with 40 preset stations for extra convenience

# PHILIPS

# Highlights

## Digital Sound Control

Digital Sound Control offers you a choice of pre-set Jazz, Rock, Pop and Classic controls you can use to optimise the frequency ranges for different musical styles. Each mode uses graphic equalizing technology to automatically adjust the sound balance and enhance the most important sound frequencies in your chosen music style. Ultimately, Digital Sound Control makes it easy for you get the most out of your music by precisely adjusting the sound balance to match the type of music you are playing.

## Dynamic Bass Boost

Dynamic Bass Boost maximizes your music enjoyment by emphasizing the bass content of the music throughout the range of volume settings - from low to high – at the touch of a button! Bottom-end bass frequencies usually get lost when the volume is set at a low level. To counteract this, Dynamic Bass Boost can be switched on to boost bass levels, so you can enjoy consistent sound even when you turn down the volume.

## Progressive Scan

Progressive Scan doubles the vertical resolution of the image resulting in a noticeably sharper picture. Instead of sending a field comprising the odd lines to the screen first, followed by the field with the even lines, both fields are written at one time. A full image is created instantaneously, using the maximum resolution. At such a speed, your eye perceives a sharper picture with no line structure.



# Specifications

## Sound

- Output Power: 2x50W + 100W RMS
- Sound Enhancement: Digital Sound Control 4 modes, Dynamic Bass Boost
- Sound System: Dolby Digital

## Loudspeakers

- Main Speaker: 4" woofer
- Subwoofer type: Passive

## Video Playback

- Playback Media: DVD+RW, DVD-Video, Picture CD, Video CD/SVCD, DivX, DVD
- Disc Playback Modes: A-B Repeat, Angle, PBC, Slow Motion, Zoom, OSD, Parental control, Resume Playback from Stop
- DVD Region.: 2
- Video Enhancement: Progressive Scan

## Audio Playback

- Playback Media: WMA-CD, MP3-CD, CD, CD-R, CD-RW
- Disc Playback Modes: 20-Track Programmable, Repeat/one/all/program, Shuffle Play
- Loader Type: Top
- USB Direct Modes: Fast Backward/Fast Forward, Play/Pause, Previous/Next, Repeat, Shuffle, Stop

## Tuner/Reception/Transmission

- Tuner Bands: FM Stereo
- Auto digital tuning
- Station presets: 40

## Connectivity

- Video Output - Analog: Component Y Pb Pr (cinch), Composite CVBS (yellow cinch), S-Video (on Hosiden), SCART
- Aux in: 1x(L/R)/ RCA
- Other connections: Digital audio coaxial out, FM Antenna, Line out
- USB: USB host

## Convenience

- Alarms: CD Alarm, Sleep timer, Radio Alarm
- Clock: On main display
- Display Type: White FTD
- OSD Languages: Spanish, French, English, German, Italian, Portuguese
- Eco Power Standby: 1 watt

## Accessories

- Included accessories: Composite video cable (Y), FM antenna
- Remote control: 38-key with Lithium battery
- Cables: D-sub

## Dimensions

- Set dimensions (W x H x D):  
218 x 90 x 221.5 mm
- Main speaker dimensions (W x H x D):  
125 x 250 x 232 mm
- Weight incl. Packaging: 13 kg
- Subwoofer dimensions (W x H x D):  
199 x 311 x 390 mm



Issue date 2014-02-06

Version: 1.0.9

12 NC: 8670 000 32902  
EAN: 87 12581 35623 1

© 2014 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)