

Philips
DVD home theater system



HTS3000

Simply sounds great

This stylish and compact digital home entertainment system plays practically any disc in high quality Dolby Digital multi-channel surround sound. So just relax and fully immerse yourself in your favorite movies and music at home.

Bring audio and video to life

- Dolby Digital and Pro Logic II surround sound
- 12-bit/108MHz video processing for sharp and natural images
- Advanced Class D Amplifier for compact, powerful sound

Play all your movies and music

- Built-in FM/MW tuner
- Plays CD, (S)VCD, DVD, DVD+R/RW, DVD-R/RW, DVD+R DL
- Plays DivX, MP3, WMA and JPEG digital camera photos

Easy to set up

- RGB on Scart single connection for high-quality video
- Easy-fit™ connectors with color-coding for a simple set-up

PHILIPS

Specifications

Picture/Display

- D/A converter: 12 bit, 108 MHz

Sound

- Total Power (RMS): 200 W
- Output power (RMS): 4 x 25W + 2 x 50W
- D/A converter: 24 bit, 192 kHz
- Frequency response: 180 - 18000 Hz
- Signal to noise ratio: >60 dB
- Sound System: Dolby Digital, Dolby Prologic II, Stereo
- Sound Enhancement: Class "D" Digital Amplifier, Night Mode
- Equalizer settings: Action, Cartoon, Classic, Concert, Drama, Gaming, Jazz, Lounge, MTV, News, Party, RnB, Rock, Sports

Video Playback

- Playback Media: CD-R/CD-RW, DVD+R/+RW, DVD-R/-RW, DVD-Video, Video CD/SVCD
- Compression formats: MPEG1, MPEG2, DivX 3.11, DivX 4.x, DivX 5.x, DivX 6.0
- Video disc playback system: PAL, NTSC

Audio Playback

- Playback Media: Audio CD, CD-R/RW, DVD+R/+RW, DVD-R/-RW
- Compression format: MP3, WMA
- MP3 bit rates: 32-256 kbps and VBR

Still Picture Playback

- Playback Media: DVD-R/-RW, CD-R/RW
- Picture Compression Format: JPEG
- Picture Enhancement: Rotate, Zoom, Flip photos, Slideshow with music playback

Tuner/Reception/Transmission

- Tuner Bands: FM, MW

Connectivity

- Rear Connections: Composite video (CVBS)

output, FM Antenna, AM/MW Antenna, AUX in, Easy-Fit Speaker Connectors, Scart

Power

- Power supply: 50Hz, 230V
- Standby power consumption: < 1 W

Loudspeakers

- Satellite speaker drivers: 3" full range woofer
- Satellite speaker impedance: 4 ohm
- Satellite speaker freq range: 150-20000 Hz
- Center Speaker: Magnetically shielded
- Center speaker drivers: 3" full range woofer
- Center speaker impedance: 8 ohm
- Center freq range: 150-20000 Hz
- Subwoofer driver: 6.5" high efficiency woofer
- Subwoofer type: Passive
- Subwoofer impedance: 8 ohm
- Subwoofer freq range: 45 - 150 Hz

Accessories

- Included accessories: Remote Control, 2 x AAA Batteries, CVBS video cable, FM antenna, AM antenna, User Manual, Quick start guide, World Wide Warranty leaflet

Dimensions

- Set dimensions (W x H x D): 360 x 55 x 332 mm
- Set weight: 2.6 kg
- Surround Speaker dimensions (W x H x D): 100 x 95 x 83 mm
- Surround speaker Weight: 0.52 kg
- Center speaker dimensions (W x H x D): 100 x 95 x 83 mm
- Center Speaker Weight: 0.59 kg
- Subwoofer dimensions (W x H x D): 131 x 315 x 386 mm
- Subwoofer Weight: 3.62 kg
- Packaging dimensions (W x H x D): 446 x 417 x 378 mm
- Weight incl. Packaging: 11.3 kg

Highlights

Plays it all

Play virtually any disc you want - whether they be CDs, (S)VCDs, DVDs, DVD+R, DVD-R, DVD+RW, DVD-RW or DVD+R DL. Experience unbeatable flexibility and the convenience of playing all your discs on the one device.

Plays it all

Play virtually any media format you want - whether they be DivX, MP3s, WMA or JPEGs. Experience the unbeatable convenience of great playability, and the luxury of sharing media files on your TV or home theater system - in the comfort of your living room.

Dolby Digital and Pro Logic II

A built-in Dolby Digital decoder eliminates the need for an external decoder by processing all six channels of audio information to provide a surround sound experience and an astoundingly natural sense of ambience and dynamic realism. Dolby Pro Logic II provides five channels of surround processing from any stereo source.

12-bit/108MHz video processing

12-bit Video DAC is a superior Digital-to-Analogue-Converter that preserves every detail of the authentic picture quality. It shows subtle shades and smoother graduation of colors, resulting in a more vibrant and natural picture. The limitation of the usual 10bit DAC become in particular apparent while using large screens and projectors.

Advanced Class D Amplifier

Advanced Class D Amplifier for compact, powerful sound

RGB on Scart connectivity

RGB on Scart is a cable connection that provides easy connectivity for high quality video output.

Easy-fit™ connectors

Color-coded connectors provide a simple and user-friendly solution to connect the speakers and subwoofer to the center unit of the home entertainment system simply by plugging the connectors in the matching colored interface at the rear of the center unit.



Issue date 2017-04-04

Version: 2.0.9

12 NC: 8670 000 25592
EAN: 87 12581 30409 6

© 2017 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com