

Philips
PhotoFrame

7" LCD
16:9 frame ratio

7FF3FPW



Share your memories

How many digital pictures are hidden on your PC? See, share, organise and relive your memories with Philips PhotoFrame™, the easiest way to share your memories by displaying your digital photos in stunning quality - without a PC.

Top-quality display for print-like pictures

- imagen for sharp and vibrant colour
- Add new glow to old memories with RadiantColor
- SmartContrast: Dynamic, optimised contrast for visual clarity

Easily display and manage your digital photos

- Have fun with collages: display multiple photos in one view
- View USB flash drive photos without a PC

Simple intuitive operation and great convenience

- Intuitive UI, 5-way keypad for easy navigation and operation
- Auto photo orientation to fit portrait or landscape modes

Green design

- Auto turning display on/off at preset times for power saving

Stylish curved design complements your photos

- Tasteful glossy finish and great feel

PHILIPS

Highlights

imagen technology

imagen is exclusive Philips photo enhancement technology that automatically analyses your photos to correct colour and adjust for optimal contrast: imagen separates colours to avoid "crosstalk", adjusts brightness distribution for great visual contrast and corrects Gamma for colour accuracy.

RadiantColor

RadiantColor is an exclusive Philips technology for displaying smaller photos in the optimal 4:3 ratio by extending the colour on the edges of a less-than-full-screen photo to the sides of the screen, eliminating black bars and aspect ratio distortion.

SmartContrast

SmartContrast is Philips technology that analyses the contents you are displaying, automatically adjusting colours and controlling backlight intensity to dynamically enhance contrast for the best digital images and optimum contrast for better entertainment when viewing videos or playing games where dark hues are displayed; when you select the Economy mode, contrast is adjusted and backlighting fine-tuned for just-right display of everyday office applications and lower power consumption.

Multiple-photo collage effect

It's a slideshow effect to show photos in collage form that automatically and randomly compiles different photos together to avoid unattractive

borders that may result from photos which are smaller than the screen size.

Viewing photos in USB flash

A USB connector for easy viewing and sharing of photos stored on a USB flash drive.

SmartPower

A timer turns PhotoFrame on and off at the times you choose, reducing energy consumption for the sake of our environment saving up to one third of your PhotoFrame energy costs.

Auto orientation

Automatic landscape/portrait recognition employs a sensor that recognises PhotoFrame orientation and displays each photo in its proper mode.



Imagen

RadiantColor

Collage

USB Connectivity

SmartPower

SmartContrast

MEMORY CARD SLOT

Lead Free

Specifications

Picture/Display

- Viewing angle: @ C/R > 10, 120° (H)/100° (V)
- Lifetime, to 50% brightness: 20,000 hr
- Brightness: 200 cd/m²
- Aspect ratio: 16:9
- Panel resolution: 480 x 234
- Contrast ratio (typical): 300:1

Connectivity

- USB: USB 2.0 Host, USB 2.0 Slave

Storage Media

- USB: USB flash drive
- Memory Card Types: Compact Flash type I, Secure Digital (SD), Secure Digital (SDHC), Multimedia Card, xD card, Memory Stick, Memory Stick Pro

Convenience

- Card Reader: Built in (2x)
- Photo format supported: JPEG photo, Up to 10 MB JPEG files, Up to 20 Megapixels
- Placement supported: Photo auto orientation, Landscape, Portrait
- Buttons and controls: 3 buttons, 4-way navigation key and enter
- Playback mode: Full screen browse, Slideshow, Thumbnail browse
- Photo edit: Copy, Delete, Rotate, Zoom & crop
- Photo effects: Black and White, Frames, Sepia, Radiant colour
- Slideshow setting: Random, Sequential, Transition effect
- Screen background: Black, White, Grey, Auto-fit
- Setup function: Brightness adjustment, Language, Status, Auto on/off, Beep on/off, Set time and date, Clock display enable/disable, Alarm
- System status: Firmware version, Remaining memory
- Connected media status: Connected media, Remaining memory

- Plug & Play Compatibility: Windows Vista, Windows 2000/XP or later, Mac OS X
- Regulatory Approvals: BSMI, C-Tick, CCC, CE, FCC, GOST, PSB, Switzerland, UL/cUL
- On-Screen Display languages: English, Spanish, German, French, Italian, Dutch, Danish, Russian, Simplified Chinese, Japanese

Accessories

- Included Accessories: AC-DC Adapter, USB cable, Stand, Quick start guide, User manual

Dimensions

- Set dimensions with stand (W x H x D): 206.4 x 139.3 x 103 mm
- Weight: 0.345 kg
- Temperature range (operation): 0°C to 40°C
- Temperature range (storage): -20°C to 70°C

Power

- Power consumption: 5 W
- Power mode supported: AC powered

Packaging dimensions

- EAN: 87 12581 41213 5
- Number of products included: 1
- Packaging type: Box
- Packaging dimensions (W x H x D): 26.1 x 22.2 x 7.8 cm
- Net weight: 0.604 kg
- Gross weight: 0.793 kg
- Tare weight: 0.189 kg

Outer Box

- GTIN: 1 87 12581 41213 2
- Number of consumer packages: 2
- Outer carton (L x W x H): 28.3 x 24.3 x 18.8 cm
- Net weight: 1.208 kg
- Gross weight: 1.988 kg
- Tare weight: 0.78 kg



Issue date 2019-04-18

Version: 4.0.14

12 NC: 8670 000 38986
EAN: 87 12581 41213 5

© 2019 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com