



Philips Streamium
Wireless Music Centre

Streamium

WAC700



My room my music



Music follows me



Music broadcast



POWERED BY



Store all your CD's in one place

Store your entire CD collection on a 40 GB hard disk and listen in every room. You can listen to different music in every room and your music can finally follow you wherever you are in your home. The Remote Control has a built-in display

Unlimited listening pleasure - wirelessly

- Wireless streaming between Music Centre and Station(s)
- Multiple user access streams to up to 5 stations streaming
- 40 GB hard disk to store and playback up to 750 CDs
- Wireless streaming from PC via UPnP

Easy navigation and control

- 2-way Remote Control for user friendly navigation
- Direct Content Access to artist, album or playlists
- Music Follows Me: take your music with you from room to room
- Music Broadcast for simultaneous playback to all Stations

Quality sound performance

- Super Sound Panel for clear and deep bass sound
- Class 'D' Digital Amplifier for quality sound performance

Expandable

- Add 4 additional Wi-Fi Stations



PHILIPS

sense and simplicity

Specifications

Sound

- **Equalizer settings:** Classic, Jazz, Pop, Rock, Techno, Neutral
- **Sound Enhancement:** Dynamic Bass Boost 3 steps, Equalizer, Incredible Surround, Treble and Bass Control, Class "D" Digital Amplifier, Smart equalizer
- **Music Power:** (80) W
- **Volume Control:** Volume Control up/down
- **Output Power:** 40W+40W Music Power

Loudspeakers

- **Built-in speakers:** 2
- **Loudspeaker types:** Super Sound Panel, Integrated subwoofer, Non-detachable

Audio Playback

- **Compression format:** MP3, WMA, PCM
- **Playback Media:** CD, CD-R, CD-RW, MP3-CD, WMA-CD
- **Disc Playback Modes:** Next/Previous Track Search, Next/Previous Album Search, 99-Track Programmable, Repeat/Shuffle/Program, Fast Forward/Backward
- ID3-tag support
- **Loader Type:** Slot
- **MP3 bit rates:** 8-320 kbps and VBR
- **WMA bit rates:** 16-128 kbps
- **Hard Disk Playback Mode:** Album, Genre, Playlist, All tracks, Same Artist, Same Genre, Uncompressed tracks
- **Hard Disk Streaming Mode:** Wi-Fi streaming to 5 stations, "My Room, My Music", "Music Follows Me", "Music Broadcast"
- **Sample frequencies:** 8-48 kHz (MP3), 16-48 kHz (WMA)

Audio Recording

- **Recording Media:** HDD
- **Recording speed:** 1 x, 4 x
- **Audio file format:** MP3

Storage Media

- :

Tuner/Reception/Transmission

- **Tuner Bands:** FM
- Auto digital tuning
- Auto store
- **Number of Preset Channels:** 40

Connectivity

- **Audio cinch in:** Analogue AUX (Centre/Station)
- **Audio cinch out:** Analogue Line-out (Centre)
- **Other connections:** Ethernet
- **Headphone:** 3.5 mm
- **Antenna:** FM Dipole
- **Wireless connections:** Wireless LAN(802.11g)
- **Power:** 220 V 50 Hz
- **Wireless Universal Plug & Play:** Enabled

Convenience

- **Display Type:** LCD, 128 x 96 dot matrix, 60.7 mm x 52.3 mm (Centre)
- Backlight
- **Backlight colour:** White
- **On-Screen Display languages:** English, Dutch, French, German, Italian, Spanish
- **Digital Content Management:** DMM software included
- **Eco Power Standby:** 1 watt
- Headphone jack
- **Wall mountable / Ceiling Throw:** Wall Mountable

Accessories

- **Cables:** Ethernet Cable
- **CD-ROM:** Installation CD-ROM, DMM and utilities software.
- **Remote control:** 2-way 6-line Display
- **Batteries:** 4 x AAA
- **Warranty Card:** Warranty card

Dimensions

- **Master carton weight:** 9 kg
- **Product dimensions (WxDxH):** 608mm x 175mm x 303mm
- **Set weight:** 7.7 kg
- **Carton dimensions (WxDxH):** 682mm x 400mm x 236mm

Product highlights

Wireless streaming

With wireless streaming, you don't need to download and store large music files on our audio device. Instead, you can listen to favourite songs as they are continuously streamed to all the Music Stations - at the same time. Have your music follow you from room to room with Music Follows Me, no need to restart navigation and playback. Music Broadcast simultaneously broadcasts your desired music from the Centre to all Stations. And with My Room, My Music, any family member can enjoy selected music from the stored collection in any room that is equipped with a Wireless Music Centre or Station.

Multiple User Access

Different family members in five different rooms can access & listen to their own choice of music from the Wireless Audio Centre at the same time.

2-way Remote Control

With Philips 2-way remote control, you can now navigate through hundreds of songs easily with the one simple press of the remote control. Displaying six lines info listed according to playlist, album, artist, genre or track, this intuitive navigation offers speedy yet simple scrolling through hundreds of files. It allows one handed operation and guarantees a unique user experience.

Direct Content Access

No more searching through hundreds of your CDs to find your favourite track by a particular artist. With the intuitive User Interface built-in the Philips Wireless Audio Centre, you can now have almost instantaneous and direct access to your stored digital music collection on the hard disc (up to 750 CDs) and go straight to the music you want to listen to, listed by Artist, Album, Playlist, Genre or Tracks.

Music Follows Me

Music follows Me feature allows you to bring your favourite music from room to room in your house without having to restart navigation and playback of that particular track. By simply pressing a button, your favourite song will follow you anywhere you go in your house.

Music Broadcast - Party mode!

Be your own DJ at your home party and simultaneously broadcast your favourite dance music from the Wireless Music Centre to all Wireless Music Stations installed in various parts of your home. Great for parties!

Super Sound Panel

Super Sound Panel is an innovative, flat speaker panel that uses cutting-edge technology to provide high quality, full-range audio from a flat and compact speaker unit.



Issue date 2007-12-06

Version: 3.0

12 NC: 9073 100 12996
EAN: 87 10895 93096 3

© 2007 Koninklijke Philips Electronics N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.

www.philips.com

* Windows logo are trademarks, or registered trademarks of Microsoft Corporation in the United States and/or other countries.
* Actual capacity less