



Philips
Micro music system

CD, MP3-CD, USB, FM
10W

MCM129

Rich and powerful sound

Obsessed with sound

Listen to all your favorites on your portable music player with USB Direct and Audio in. This Philips Micro sound system also plays MP3-CD and CD-R/RW, and features Bass Reflex speakers for powerful and dramatic bass.

Enjoy your music from multiple sources

- Play MP3-CD, CD and CD-R/RW
- USB Direct for easy MP3 music playback
- Audio-in for portable music playback

Enrich your sound experience

- 10W RMS total output power
- Bass Reflex Speaker System delivers a powerful, deeper bass
- Digital Sound Control for optimized music style settings

Easy to use

- Digital tuning with preset stations for extra convenience
- Handy remote control

PHILIPS

Specifications

Sound

- Sound enhancement: Dynamic Bass Boost
- Maximum output power (RMS): 10W

Loudspeakers

- Speaker drivers: 3.5" woofer
- Speaker types: bass reflex speaker system

Audio playback

- Disc playback modes: fast forward/backward, next/previous track search, repeat/shuffle/program
- Playback media: CD, CD-R/RW, MP3-CD, USB flash drive
- USB Direct playback modes: fast backward/fast forward, play/pause, previous/next, repeat, shuffle, stop

Tuner/Reception/Transmission

- Station presets: 20
- Antenna: FM fixed pigtail antenna
- Tuner Bands: FM

Connectivity

- USB: USB host
- Audio in (3.5mm)



Convenience

- Display type: LED display
- Loader type: top

Accessories

- Included accessories: User Manual
- Remote control: 15-key remote

Dimensions

- Main unit width: 180 mm
- Main unit height: 119 mm
- Main unit depth: 220.4 mm
- Main speaker dimensions (W x D): 127 x 160 mm
- Main speaker height: 170 mm
- Packaging width: 659 mm
- Packaging height: 234 mm
- Packaging depth: 180 mm
- Gross weight: 4.6 kg
- Net weight: 3.94 kg

Power

- Power supply: 220-240V

Highlights

Bass Reflex Speaker System



Bass Reflex Speaker System delivers a deep bass experience from a compact loudspeaker box system. It differs from a conventional loudspeaker box system in the addition of a bass pipe that is acoustically aligned to the woofer to optimize the low frequency roll-off of the system. The result is deeper controlled bass and lower distortion. The system works by resonating the air mass in the bass pipe to vibrate like a conventional woofer. Combined with the response of the woofer, the system extends the overall low frequency sounds to create a whole new dimension of deep bass.

Audio-in



The Audio in connectivity allows direct playback of Audio in content from portable media players. Besides the benefit of enjoying your favorite music in the superior sound quality delivered by the audio system, the Audio in is also extremely convenient as all you have to do is to plug your portable MP3 player to the audio system.

USB Direct for easy MP3 music



Thanks to the complete file transferability, you can easily enjoy the convenience and fun of accessing more digital music via the built-in USB Direct.



Issue date 2014-06-12

Version: 1.0.4

12 NC: 8670 001 09457
EAN: 87 12581 70332 5

© 2014 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com