

DVD, MP3-CD and WMA-CD playback

You're in touch with the latest and the coolest - now get a load of the hot 2-in-1 Micro Hi-Fi with DVD and MP3-CD/WMA-CD playback! Relax to your fave movies and music. Home entertainment will never be the same again!

Enjoy your favourite movies, photos and music

- Play DVD, (S)VCD, MP3-CD, WMA-CD, CD(RW) and Picture CD
- Dolby Digital, DTS Digital Out
- 10 hours of MP3-CD or 20 hours of WMA-CD music

Enrich your sound experience

- Incredible Surround™ for enhanced audio enjoyment
- Digital Sound Control for optimised music style settings
- Dynamic Bass Boost delivers deeper, more dramatic bass
- 2x25W RMS/1000W PMPO

Start the day your way

- Wake up & sleep timer
- Logic tape deck
- The digital tuner has 40 presets for extra convenience

Your personal karaoke show

- Enjoy endless Karaoke entertainment and fun at home



PHILIPS

Technical specifications

Sound

- **Sound enhancement:** Incredible surround, Digital sound control 4 modes, Dynamic Bass Boost
- **Sound system:** Dolby Digital, DTS Digital Out
- **Output power:** 2x25 watts RMS, 1000 watts PMPO

Loudspeakers

- **Main speaker:** 2 way, 4" woofer, Bass reflex speaker system, Piezo tweeter, Speaker grilles detachable

Video playback

- **Disc playback media:** DVD+RW, DVD-Video, Video CD/SVCD, Picture CD
- **DVD region:** 3
- **Disc playback modes:** Zoom, Slow motion, Resume Playback from Stop, A-B Repeat

Audio Playback

- **Disc playback media:** WMA-CD, MP3-CD, CD-R, CD-RW, CD
- **Disc playback modes:** 20 track programmable, Repeat / one / all / program, Shuffle play
- **ID3 tag support**
- **Loader type:** Top
- **Cassette deck technology:** Logic
- **Cassette playback modes:** Electronic Speed Control, Full auto stop, Tape counter

Audio Recording

- **Recording media:** Tape
- **Tape recording enhancement:** CD synchro start recording, Timer for recording from tuner, Automatic Recording Level

Tuner / Reception / Transmission

- **Tuner bands:** FM stereo, MW

- **Auto digital tuning**
- **Station presets:** 40
- **Tuner enhancements:** Auto store

Connectivity

- **Video output - analogue:** Component Y Pb Pr (cinch), Composite CVBS (yellow cinch), S-Video (on Hosiden)
- **Other connections:** Active subwoofer Pre-out, Digital coaxial out, Line out, FM antenna, MW antenna
- **Aux in:** 2x(L/R)/ RCA
- **Headphone:** 3.5 mm

Convenience

- **Karaoke:** MIC volume, Key control, Echo control
- **Alarms:** Sleep timer
- **Clock:** On main display
- **Display type:** VFD display
- **OSD languages:** English, French, Spanish, Portuguese, Chinese
- **Eco power standby:** 1 watt

Accessories

- **Included accessories:** Composite video cable (Y), Audio cable, FM/MW antenna
- **Remote control:** 45-key with 2xAA batteries

Dimensions

- **Set dimensions (W x H x D):** 175 x 254 x 315 mm
- **Main speaker dimensions (W x H x D):** 175 x 254 x 214 mm
- **Packaging dimensions (W x H x D):** 408 x 348 x 524 mm
- **Weight incl. packaging:** 12.9 kg

Product highlights

MP3-CD or WMA-CD playback

MP3 is a revolutionary compression technology by which large digital music files can be made up to 10 times smaller without radically degrading their audio quality. A single CD can store up to 10 hrs of music. MP3 has become the standard audio compression format, allowing quick and easy audio file transfer. Windows Media Audio (WMA) is a highly compressed digital audio format from Microsoft that delivers great sound with music files that take up half the disk space and download in half the time. A single CD can store up to 20 hours of good quality WMA music recorded at a bit rate of 64 Kbps.

Incredible Surround™

Incredible Surround™ is an audio technology from Philips that dramatically magnifies the sound field to immerse you in the audio. Using state-of-the-art electronic phase shifting, Incredible Surround™ mixes sounds from left and right in such a way that it expands the virtual distance between the two speakers. This wider spread greatly enhances the stereo effect and creates a more natural sound dimension. Incredible Surround™ allows you to experience total surround with greater depth and width of sound, without the use of additional speakers.

Digital sound control

Digital Sound Control lets you select from pre-set modes that control the frequency bands of sound to optimise certain musical styles. You can choose between different sound settings - Optimal, Jazz, Rock, Techno, Pop or Classic. Each mode uses graphic equalising technology to automatically adjust the sound balance and enhance the most important sound frequencies in your chosen music style. Digital Sound Control lets you get the most out of your music by adjusting the sound balance to match the music type you are playing.

Dynamic Bass Boost

Dynamic Bass Boost maximises your music enjoyment by emphasising the bass content of the music throughout the range of volume settings - from low to high - at the touch of a button! Bottom-end bass frequencies usually get lost when the volume is set at a low level. To counteract this, Dynamic Bass Boost can be switched on to boost bass levels, so you can enjoy consistent sound even when you turn down the volume.

Karaoke

The Karaoke feature on your DVD player provides endless entertainment and maximum audio and singing enjoyment. You can enhance your performance by adding an 'echo' effect to your voice. The key controls allow you to choose the optimal key for your personal vocal range.



Date of issue 2005-09-21

Version: 4.0

12 NC: 9073 100 12987
EAN: 87 10895 92294 4

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.
© 2005 Koninklijke Philips Electronics N.V.
All Rights reserved.
www.philips.com