

Philips  
DVD player



DVP1013



## Simply plays it all

Introducing a dream player that promises flawless, true-to-life picture quality and the ability to play virtually any disc! This Philips DVD player delivers your movies and music entertainment experience right in your personal environment.

### **Bring audio and video to life**

- 12-bit/108MHz video processing for sharp and natural images
- 192kHz/24 bit audio DAC enhances analogue sound input
- High quality outputs for analog and digital audio
- Progressive Scan component video for optimized image quality

### **Play all your movies and music**

- Plays MP3, WMA and JPEG digital camera photos
- Plays CD, (S)VCD, DVD, DVD+R/RW, DVD-R/RW

### **Fits any space, any lifestyle**

- Ultra-slim design that fits anywhere

**PHILIPS**  
sense and simplicity

# Specifications

## Picture/Display

- D/A converter: 12 bit, 108 MHz
- Picture enhancement: Progressive scan, Video upsampling

## Sound

- Crosstalk (1kHz): 70 dB
- D/A converter: 24 bit, 192 kHz
- Dynamic Range (1kHz): 80 dB
- Frequency response: 30-20000 Hz
- Signal to noise ratio: 90
- Distortion and Noise (1kHz): 65 dB

## Video Playback

- Compression formats: MPEG1, MPEG2
- Playback Media: CD-R/CD-RW, DVD+R/+RW, DVD-R/-RW, DVD-Video, Video CD/SVCD, CD, DVD
- Video disc playback system: NTSC, PAL

## Audio Playback

- Compression format: Dolby Digital, MP3, PCM, WMA
- Playback Media: Audio CD, CD-R/RW, CD, MP3-CD, MP3-DVD, WMA-CD
- MP3 bit rates: 32 - 256 kbps

## Still Picture Playback

- Picture Compression Format: JPEG

- Picture Enhancement: Flip photos, Rotate, Slideshow, Zoom
- Playback Media: DVD+R/+RW, DVD-R/-RW, CD-R/RW, Kodak Picture CD, Picture CD

## Connectivity

- Rear Connections: Analog audio Left/Right out, Composite video (CVBS) output, Digital coaxial out, ComponentVideo out Progressive

## Accessories

- Included accessories: 2 x AAA Batteries, Audio/Video cable, Remote Control, Product Registration Card, User Manual, World Wide Warranty leaflet

## Dimensions

- Packaging dimensions (W x H x D): 304 x 95 x 288 mm

## Power

- Power consumption: < 10 W
- Power supply: 120V, 60Hz
- Standby power consumption: < 1 W

## Convenience

- Child Protection: Child Lock, Parental Control
- On-Screen Display languages: Canadian French, English, Mexican Spanish

# Highlights

## Plays it all

Play MP3s, WMA and JPEGs, and experience the convenience of sharing media files on your TV or home theater system - in the comfort of your living room.

## 192kHz/24 bit audio DAC

192KHz sampling enables you to have an accurate representation of the original sound curves. Together with a 24-bit resolution, more information is captured from the original analogue sound wave form, giving a much richer audio reproduction.

## Progressive Scan

Progressive Scan doubles the vertical resolution of the image resulting in a noticeably sharper picture. Instead of sending a field comprising the odd lines to the screen first, followed by the field with the even lines, both fields are written at one time. A full image is created instantaneously, using the maximum resolution. At such a speed, your eye perceives a sharper picture with no line structure.



Issue date 2012-08-08

Version: 1.0.10

12 NC: 8670 000 31923  
UPC: 6 09585 13688 5

© 2012 Koninklijke Philips Electronics N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.

[www.philips.com](http://www.philips.com)