

Philips
Sleek micro sound system

• dock for iPhone/iPod

MCM280D



Obsessed with sound

Sound that fits your home

Enjoy your iPhone/iPod music in superb sound with the Philips micro hi-fi system MCM280D. Stylishly designed, it also charges your iPhone/iPod while it plays, rips CDs to MP3, and plays MP3/WMA music from portable devices via USB Direct.

Unlimited listening pleasure

- Play and charge your iPod/iPhone simultaneously
- Rip your favorite CDs to MP3
- Enjoy MP3/WMA music directly from your portable USB drives
- Play MP3/WMA-CD, CD and CD-RW
- MP3 Link for portable music playback

Enrich your sound experience

- All-in-one remote control for your system and iPod/iPhone
- Digital Sound Control for optimized music style settings
- Dynamic Bass Boost for deep and dramatic sound
- 60W RMS total output power

Design that blends into your interior

- Front motorized CD door with viewing window
- Stylishly sleek and compact design

Sleek micro sound system
dock for iPhone/iPod

MCM280D/12

Highlights

Play & charge your iPod/iPhone

Enjoy your favorite MP3 music while charging your iPod/iPhone! The dock lets you connect your portable device directly to the Docking entertainment system so you can listen to your favorite music in superb sound. It also charges your iPod/iPhone while it plays so you can enjoy your music and not have to worry about your portable player battery running out. The Docking entertainment system automatically charges your portable device while it is docked.

Rip your favorite CDs to MP3

Simply plug in your USB mass storage device to the USB port on Philips audio system and start recording your favorite music from CDs to your USB device or MP3 player - with one

touch and no computer needed. So you can create your own MP3 files via direct MP3 digital recording.

USB Direct for MP3/WMA music

Simply plug in your device to the USB port on your Philips Hi-Fi system. Your digital music will be played directly from the device. Now you can share your favorite moments with family and friends.

Digital Sound Control

Digital Sound Control offers you a choice of pre-set Jazz, Rock, Pop and Classic controls you can use to optimise the frequency ranges for different musical styles. Each mode uses graphic equalizing technology to automatically adjust the sound balance and enhance the most

important sound frequencies in your chosen music style. Ultimately, Digital Sound Control makes it easy for you get the most out of your music by precisely adjusting the sound balance to match the type of music you are playing.

Dynamic Bass Boost

Dynamic Bass Boost maximizes your music enjoyment by emphasizing the bass content of the music throughout the range of volume settings - from low to high - at the touch of a button! Bottom-end bass frequencies usually get lost when the volume is set at a low level. To counteract this, Dynamic Bass Boost can be switched on to boost bass levels, so you can enjoy consistent sound even when you turn down the volume.



Specifications

Sound

- Output power: 2 x 30 W RMS, 2 x 60 W music power
- Sound enhancement: digital sound control 4 modes, Dynamic Bass Boost

Loudspeakers

- Speaker drivers: 4" woofer
- Speaker types: bass reflex speaker system

Audio playback

- Playback media: CD, CD-R, CD-RW, MP3-CD, WMA-CD
- Disc playback modes: repeat/shuffle/program
- Others: ID3-tag support
- USB Direct playback modes: fast backward/fast forward, play/pause, previous/next, program play, repeat, shuffle, stop

Tuner/Reception/Transmission

- Tuner bands: FM stereo
- Station presets: 40
- Antenna: FM antenna
- RDS: program type, station name, radio text, RDS clock set, news
- Tuner enhancement: auto digital tuning, auto scan

Connectivity

- Audio/Video output: Headphone (3.5mm)
- MP3 Link: 3.5mm stereo line in
- USB: USB host

Convenience

- Alarms: CD alarm, radio alarm, USB alarm, iPod alarm
- Clock: on main display, sleep timer
- Loader type: front, motorised
- Display type: LCD display
- Backlight color: blue

Accessories

- Cables/Connection: AC-DC adapter, power cord
- Remote control: 40-key with lithium battery
- Others: cradle and adaptors for iPhone/iPod, FM antenna, Quick start guide, stand
- User Manual: multi-languages
- Warranty: World Wide Guarantee booklet

Dimensions

- Gross weight: 6 kg
- Main speaker dimensions (W x D): 158 x 193 mm
- Main speaker height: 250 mm
- Main unit depth: 160 mm
- Packaging width: 397 mm
- Main unit height: 250 mm
- Packaging height: 339 mm
- Main unit width: 211 mm
- Packaging depth: 311 mm

Audio recording

- Recording media: USB device
- USB recording modes: instant record, programmed tracks, single disc, single track
- USB recording sources: CD

Power

- Power supply: 100 - 240V AC, 50/60Hz

iPhone compatibility

- Compatible with: iPhone, iPhone 3G

Green

- Eco Power standby: 1 W

iPod compatibility

- Compatible with: iPod, iPod 5th generation, iPod classic, iPod mini, iPod nano 1st generation, iPod nano 2nd generation, iPod nano 3rd generation, iPod nano 4th generation, iPod touch, iPod touch 2nd generation, iPod with color display



Issue date 2013-05-10

Version: 1.2.3

12 NC: 8670 000 49771
EAN: 87 12581 46565 0

© 2013 Koninklijke Philips Electronics N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips
Electronics N.V. or their respective owners.

www.philips.com