



Philips  
Portable DVD Player

22.9 cm/9" widescreen LCD

PET988



## Enjoy your favorite movies and photos

with a 2-position sliding screen

Play your favorite movies, photo slideshows and music on the Philips portable DVD player PET988! Match your home design with the interchangeable frames for the 9" color LCD display and enjoy yourself with contents from multiple sources.

### A wide variety of entertainment

- 22.9 cm (9") TFT color widescreen LCD display
- Play DVD, DVD+/-R and DVD+/-RW, (S)VCD, DivX® & MPEG4 movies
- Plays MP3-CD, CD and CD-RW music
- Built-in stereo speakers for quality sound

### Easily display your digital photos

- Display photos and photo slideshows
- View photos directly from memory cards, USB, DVDs and CDs
- Additional frame to fit your home

### Great convenience

- Handy remote control for extra convenience
- AV-out connector to TV
- Time and date display
- Touch sensitive keys for intuitive control
- Stereo headphone jack for better personal music enjoyment

# PHILIPS

# Highlights

## Play DVD, DivX and MPEG4

With DivX<sup>®</sup> support, you are able to enjoy DivX<sup>®</sup> encoded videos in the comfort of your living room. The DivX<sup>®</sup> media format is an MPEG4-based video compression technology that enables you to save large files like movies, trailers and music videos on media like CD-R/RW, memory cards and DVD-video. DivX<sup>®</sup> CDs can be played back on selected DVD

players, DVD Recorders and Home Theater Systems.

## MP3-CD, CD and CD-RW music

MP3 is a revolutionary compression technology by which large digital music files can be made up to 10 times smaller without radically degrading their audio quality. A single CD can store up to 10 hours of music.

## Additional frame

An additional frame that snaps onto your portable DVD player to fit your personal taste and compliments your home or office decor.

## Touch sensitive keys

With the touch sensitive keys, a light touch on the keys suffices to register your input. No need for pressing hard on the keys on your product anymore!



# Specifications

## Picture/Display

- Diagonal screen size (inch): 9 inch
- Display screen type: LCD TFT
- Resolution: 640(w)x220(H)x3(RGB)
- Brightness: 150 cd/m<sup>2</sup>
- LCD panel type: Anti-glare polarizer
- Contrast ratio (typical): 250:1
- Effective viewing area: 202.56(W) × 105.27(H)
- Pixel pitch: 0.1055(H) × 0.4785(H)
- Response time (typical): 30 ms

## Sound

- Output Power: 500mW RMS(built-in speakers)
- Output power (RMS): 10mW RMS(earphone)
- Signal to noise ratio: >80dB(earphone), >62dB(built-in speakers)

## Video Playback

- Playback Media: DVD, Picture CD, SVCD, Video CD, DVD-R/-RW, MP3-CD, CD-R/CD-RW, DVD+R/+RW, CD
- Disc Playback Modes: A-B Repeat, Angle, Disc Menu, Fast Backward, Fast Forward, OSD, Repeat, Shuffle Play, Slow Backward, Slow Forward, Zoom
- Video disc playback system: NTSC, PAL
- Compression formats: Divx, MPEG4

## Audio Playback

- Compression format: Dolby Digital, MP3

- MP3 bit rates: 32 - 320 kbps
- Playback Media: CD, CD-RW, MP3-CD, CD-R
- File systems supported: ISO-9660, Joliet

## Connectivity

- DC in: 9V
- Headphone jack: 3.5mm Stereo Headphone
- AV output: Composite (CVBS) x1
- SD/MMC card slot: SD card reader
- USB

## Accessories

- AC/DC Adaptor: DC-IN 9V, 110-240v, 50/60Hz
- Remote control: Slim remote
- Cables: 1 x AV Cables
- User Manual: 16 languages

## Dimensions

- Master carton dimensions: 405 x 353 x 250 mm
- Master carton quantity: 3
- Master carton weight: 6.8 kg
- Packaging dimensions (W x H x D): 340 x 240 x 133 mm
- Product dimensions (W x H x D): 270 x 210 x 105 mm
- Packaging type: D-box
- Product weight: 2 kg



Issue date 2017-04-05

Version: 1.0.8

12 NC: 8670 000 39723  
EAN: 87 12581 42293 6

© 2017 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)