

Philips Portable DVD Player

PET810

Enjoy DVD and digital videos on the go

The PET810 is your compact mobile entertainment pal! Savor DVDs on an 20.3 cm (8") TFT LCD display. Enjoy multi-media ease with MPEG4 and DivX with digital media format. Rechargeable battery and car adaptor provide power on the go.

Immerse in AV entertainment on the go

- Play, DVD, DVD+R and DVD+RW
- DivX playback for high compression video
- MPEG4 playback ensures high-quality compressed video
- Plays CD-RW and MP3-CD

Cmfortable viewing anywhere

- 20.3 cm (8") TFT LCD for a comfortable viewing experience
- Watch movies in 16:9 widescreen format

The ultimate in convenience

- Car adaptor and handy remote control included
- Up to 2.5-hour playback with rechargeable battery
- Dual headphone jacks for the share of entertainment fun



Highlights

Play DVD, DVD+R and DVD+RW

The Philips player is compatible with most DVD and CD discs available in the market. DVD, DVD+R and DVD+RW discs - all of them can play on the player. DVD+RW is a shorthand term for a DVD drive that can accept the common recordable DVD format. Likewise, DVD+RW handles the common rewritable disc type.

DivX playback

With DivX support, you are able to enjoy DivX encoded videos in the comfort of your living room. The DivX media format is an MPEG4-based video compression technology that enables you to save large files like movies, trailers and music videos on media like CD-R/RW, memory cards and DVD-video. DivX CDs can be played back on selected DVD players, DVD Recorders and Home Theater Systems.

MPEG4 playback

MPEG4 is a compression standard allows you to record movies at up to seven to 10 times smaller than the MPEG2 standard without compromising on the picture and sound quality. MPEG4 media can be saved on a CD-Rom, memory card or DVD disc and can be played back in selective DVD players, DVD recorder and Home theater systems.

Plays CD-RW and MP3-CD

Plays CD-RW and MP3-CD

20.3 cm (8") TFT LCD

20.3 cm (8") TFT LCD for a comfortable viewing experience

16:9 widescreen format

Display and share your movies and digital photos with your friends and family. The 16:9 widescreen aspect ratio is standard for universal to high-definition digital television. A

native 16:9 aspect ratio means video display without bars at top and bottom of the picture and without the quality loss than comes from scaling, altering an image to fit on a different screen size.

Car adaptor and handy remote

Besides the car adaptor included for in-vehicle usage, you can also use the portable player to enjoy your DVDs at home by simply connecting it to your TV. Sit back and relax to your favorite DVDs by using the remote control provided to control the playback function.

2.5 hrs battery life for movie

Up to 2.5-hour playback with rechargeable battery

Dual headphone jacks

Dual headphone jacks for the share of entertainment fun















Specifications

Picture/Display

- Display screen type: LCD TFT
- · LCD panel type: Anti-glare polarizer
- Diagonal screen size (inch): 8 inch
- Resolution: 480(w)x234(H)x3(RGB)
- Brightness: 400 cd/m²
- Contrast ratio (typical): 250:1
- Effective viewing area: 176.4X99.2mm
- Pixel pitch: 0.1225(w)x0.424(H)mm
- Response time (typical): 30 ms

Sound

- Output Power: 250mW RMS(built-in speakers)
- Output power (RMS): 10mW RMS(earphone)
- Signal to noise ratio: >80dB(earphone), >62dB(built-in speakers)

Video Playback

- Playback Media: DVD, DVD+RW, DVD+R, Picture CD. SVCD. Video CD
- Compression formats: DivX 3.11, DivX 4.x, DivX 5.x, MPEG4
- Disc Playback Modes: OSD, A-B Repeat, Angle, Disc Menu, Fast Backward, Fast Forward, Repeat, Shuffle Play, Slow Backward, Slow Forward, Zoom
- · Video disc playback system: NTSC, PAL

Audio Playback

- · Compression format: Dolby Digital, MP3
- Playback Media: CD, CD-R, CD-RW, MP3-CD

- File systems supported: ISO-9660, Jolliet
- MP3 bit rates: 32 320 kbps

Connectivity

- Audio Output Analog: Audio L/R (cinch)Audio Output Digital: Coaxial (cinch)
- Video Output Analog: Video (3.5mm jack) 1x
- Connector: 2 x 3.5 mm Headphones
- DC in: 9V

Convenience

- Shock proof
- · Battery charging indication

Accessories

- Battery pack: DV 9V, Li-ion rechargeable batteries
- AC/DC Adaptor: ADPV18A(110-240v, 50/60Hz)
- Car kit: cigarette outlet adaptor, 12vDC
- Remote control: RC810(credit card style, 38 keys)
- Cables: Audio Cable x1 , Video Cable x1
- User Manual: Eng, Spa, Fre

Dimensions

- Master carton dimensions: 525 x 420 x 320 mm
- Master carton quantity: 5
 Packaging dimensions (W x H x D): 364 x 77 x 242 mm
- Product dimensions (W x H x D): 220 x 29 x 155 mm
- Product weight: 0.9 kg
- · Packaging type: Clamshell




Issue date 2011-06-07

Version: 3.0.7

@ 2011 Koninklijke Philips Electronics N.V. All Rights reserved.

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.

12 NC: 9073 101 01987 www.philips.com



charge cycles vary by use and settings.

* DivX, DivX Certified, and associated logos are trademarks of DivXNetworks, Inc. and are used under license.