

Philips Streamium
Micro Audio System



Streamium

MC-I250

Don't Dream it. Stream it.

Leading edge in micro systems, with wireless broadband internet connection and MP3 playback.

Listen to online music anywhere in your home

- Wireless Internet access to multiple online music services
- Wireless PC Link to all MP3 & mp3PRO music files on your PC

Deep bass you can hear and feel

- wOOx™ loudspeaker Technology for deep and powerful bass

Stay up-to-date

- Keep your Streamium Micro System up-to-date

PHILIPS

Specifications

Sound

- Output Power: 2 x 100 watts music power
- Sound Enhancement: Incredible Surround, Treble and Bass Control, wOOx technology

Loudspeakers

- Main Speaker: 2-way, Bass Reflex Speaker System, 5.25" Flat Metal Cone, Cone Dome Tweeter, wOOx Bass Radiator, Speaker grilles detachable

Audio Playback

- Playback Media: CD, CD-R, CD-RW, MP3-CD, mp3PRO-CD
- Disc Playback Modes: Favourites for CD and MP3-CD, Repeat one/album/all, Shuffle Play, Track info via auto CDDB CD
- Internet audio: Andante Radio: classical music, MusicMatch - personal radio, MP3.com - music charts, Radio Free Virgin, Live365:1000's Internet station, INFO: get music info via mail
- Loader Type: Motorised, Tray
- PC Link playback mode: MP3 streaming via network

Tuner/Reception/Transmission

- Auto digital tuning
- RDS: Station Name, Radio Text, RDS Clock Set
- Station presets: 40
- Tuner Bands: FM Stereo, MW, LW
- Tuner Enhancements: Auto Store, Easy Set (Plug and Play)



Connectivity

- Aux in: Line in
- Headphones: 3.5 mm
- LAN wired: Ethernet (RJ 45) 1 x
- LAN wireless: Wireless LAN (IEEE802.11b)
- Other connections: FM Antenna, MW Antenna, Line out, Subwoofer pre-out

Convenience

- Alarms: CD Alarm, PC Link alarm, Radio Alarm, Sleep timer
- Clock: Internet time, On main display
- Display Type: LCD
- Indications: DIM mode
- Eco Power Standby: 0.5 watt
- No. of different user profiles: 5

Accessories

- Included accessories: AC Power Cord, Ethernet cable, FM/MW Antenna
- Remote control: 45-key with 2 x AA batteries

Dimensions

- Set dimensions (W x H x D): 175 x 244 x 322 mm
- Main speaker dimensions (W x H x D): 180 x 244 x 215 mm
- Packaging dimensions (W x H x D): 602 x 271 x 550 mm
- Weight incl. Packaging: 13 kg

Highlights

Wireless broadband access

Wireless Internet access to multiple online music services

Wireless PC Link to music file

If you've already got a range of digital music files stored on your PC, there's no need to waste or repeat all that work! Your Micro system becomes part of your home network, connected to both the internet and your PC Link via the gateway router. By pressing the PC Link button on the set, you have instant access to the music files stored on your hard drive. And, even better, you get to play them through the Micro system's crisp, clear, powerful, patented wOOx speakers!

wOOx™ Technology

wOOx technology is a revolutionary loudspeaker concept that allows you to hear and feel profoundly deep bass that is richer than any other audio system. Special speaker drivers work in harmony with the wOOx bass radiator, and precise tuning between the main driver and the tweeter ensures smooth transitions from low-mid to high frequencies. Dual suspension and a totally symmetrical sandwich construction deliver low and precise base without noticeable distortion. wOOx produces exceptionally deep and dynamic bass by using the speaker box full volume to truly magnify the impact of the music.

Keep your Streamium up-to-date

Keep your MCi250 up to date. Simply use your Internet connection to download and install software updates for exciting new services and product features.



Issue date 2016-11-16

Version: 5.0.6

12 NC: 9073 100 11473
EAN: 87 10895 76229 8

© 2016 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com