

PHILIPS

Micro Audio System

Streamium

MC-1250



Don't Dream it. Stream it.

Leading edge in micro systems, with wireless broadband internet connection and MP3 playback.

Listen to online music anywhere in your home

- Wireless Internet access to multiple online music services
- Wireless PC Link to all MP3 & mp3PRO music files on your PC

Deep bass you can hear and feel

- wOOx™ loudspeaker Technology for deep and powerful bass

Stay up-to-date

- Keep your Streamium Micro System up-to-date

Specifications

Sound

Output Power: 2 x 100 watts music power

Sound Enhancement: Incredible Surround, Treble and Bass Control, wOOx technology

Loudspeakers

Main Speaker: 2-way, Bass Reflex Speaker System, 5.25" Flat Metal Cone, Cone Dome Tweeter, wOOx Bass Radiator, Speaker grilles detachable

Connectivity

Aux in: Line in

LAN wired: Ethernet (RJ 45) 1 x

Other connections: FM Antenna, MW Antenna, Line out, Subwoofer pre-out

LAN wireless: Wireless LAN (IEEE802.11b)

Headphones: 3.5 mm

Tuner/Reception/Transmission

Auto digital tuning

Tuner Enhancements: Auto Store, Easy Set (Plug and Play)

Tuner Bands: FM Stereo, MW, LW

Station presets: 40

RDS: Station Name, Radio Text, RDS Clock Set

Convenience

Alarms: CD Alarm, PC Link alarm, Radio Alarm, Sleep timer

Display Type: LCD

Clock: Internet time, On main display

Eco Power Standby: 0.5 watt

Indications: DIM mode

No. of different user profiles: 5

Accessories

Included accessories: AC Power Cord, Ethernet cable, FM/MW Antenna

Remote control: 45-key with 2 x AA batteries

Dimensions

Packaging Depth: 550 mm

Set Width: 175 mm

Weight incl. Packaging: 13 kg

Packaging Height: 271 mm

Set Height: 244 mm

Packaging Width: 602 mm

Set Depth: 322 mm

Main speaker depth: 215 mm

Main speaker width: 180 mm

Main speaker height: 244 mm

Audio Playback

Disc Playback Modes: Favourites for CD and MP3-CD, Repeat one/album/all, Shuffle Play, Track info via auto CDDB CD

Playback Media: CD, CD-R, CD-RW, MP3-CD, mp3PRO-CD

Loader Type: Motorised, Tray

Internet audio: Andante Radio: classical music, MusicMatch - personal radio, MP3.com - music charts, Radio Free Virgin, Live365:1000's Internet station, INFO: get music info via mail

PC Link playback mode: MP3 streaming via network

Highlights

Wireless broadband access

Wireless Internet access to multiple online music services

Wireless PC Link to music file

If you've already got a range of digital music files stored on your PC, there's no need to waste or repeat all that work! Your Micro system becomes part of your home network, connected to both the internet and your PC Link via the gateway router. By pressing the PC Link button on the set, you have instant access to the music files stored on your hard drive. And, even better, you get to play them through the Micro system's crisp, clear, powerful, patented wOOx speakers!

wOOx™ Technology



wOOx technology is a revolutionary loudspeaker concept that allows you to hear and feel profoundly deep bass that is richer than any other audio system. Special speaker drivers work in harmony with the wOOx bass radiator, and precise tuning between the main driver and the tweeter ensures smooth transitions from low-mid to high frequencies. Dual suspension and a totally symmetrical sandwich construction deliver low and precise base without noticeable distortion. wOOx produces exceptionally deep and dynamic bass by using the speaker box full volume to truly magnify the impact of the music.

Keep your Streamium up-to-date

Keep your MCi250 up to date. Simply use your Internet connection to download and install software updates for exciting new services and product features.

