

Philips
DVD player with USB

DivX playback

DVP3260



Straight from USB to TV

With Hi-Speed USB 2.0 Link

Your dream player with flawless, true-to-life picture quality and the ability to play virtually any disc! The Philips DVD player delivers your movies and music entertainment experience.

Bring audio and video to life

- 12-bit/108 MHz video processing for sharp and natural images
- 192 kHz/24-bit audio DAC enhances analogue sound input
- Progressive Scan component video for optimised image quality

Connect and enjoy multiple sources

- Hi-Speed USB 2.0 Link plays video/music from USB flash drives

Easy to use

- One-touch MP3 creation directly from CDs onto USB sticks

Play all your movies and music

- Plays DivX, MP3, WMA and JPEG digital camera photos
- Plays CD, (S) VCD, DVD, DVD+R/RW, DVD-R/RW
- DivX Certified for standard playback of DivX videos

PHILIPS

Specifications

Picture/Display

- D/A converter: 12-bit, 108 MHz
- Picture enhancement: Progressive scan, Video upsampling

Sound

- D/A converter: 24-bit, 192 kHz
- Frequency response: 30-20,000 Hz
- Signal to noise ratio: > 100 dB
- Distortion and Noise (1 kHz): > 85 dB
- Crosstalk (1 kHz): > 100 dB
- Dynamic Range (1 kHz): > 90 dB
- Sound System: Dolby Digital

Video Playback

- Playback Media: CD, CD-R/CD-RW, Video CD/SVCD, DVD, DivX, DVD+R/+RW, DVD-R/-RW, DVD-Video
- Compression formats: MPEG1, MPEG2, DivX 3.11, DivX 4.x, DivX 5.x, DivX 6.0
- Video disc playback system: PAL, NTSC

Audio Playback

- Playback Media: CD, MP3-CD, MP3-DVD, WMA-CD, CD-R/RW, Audio CD
- MP3 bit rates: 32 - 320 kbps
- Compression format: MP3, Dolby Digital, PCM, WMA

Still Picture Playback

- Playback Media: DVD+R/+RW, DVD-R/-RW, CD-R/RW, Picture CD, Kodak Picture CD
- Picture Compression Format: JPEG
- Picture Enhancement: Flip photos, Rotate, Zoom,

Slideshow

Multimedia Applications

- Playback Formats: DivX, JPEG Still pictures, MP3
- Multimedia connections: USB memory class device

Connectivity

- Rear Connections: Analogue audio Left/Right out, Component/Video out Progressive, Composite video (CVBS) output, Digital coaxial out, Scart
- Front/Side connections: USB

Convenience

- Child Protection: Child Lock, Parental Control
- On-Screen Display languages: English

Power

- Power consumption: < 10 W
- Power supply: 50 Hz, 240 V
- Standby power consumption: < 1 W

Accessories

- Included accessories: 2 x AAA Batteries, Remote Control, World Wide Warranty leaflet, User Manual

Dimensions

- Packaging dimensions (W x H x D): 480 x 80 x 282 mm
- Set dimensions (W x H x D): 360 x 37 x 209 mm
- Set weight: 1.3 kg
- Weight incl. Packaging: 2.4 kg

Highlights

Plays it all

Play virtually any media format you want - whether it is DivX, MP3, WMA or JPEG. Experience the unbeatable convenience of great playability and the luxury of sharing media files on your TV or home theatre system - in the comfort of your living room.

192 kHz/24-bit audio DAC

192 kHz sampling enables you to have an accurate representation of the original sound curves. Together with a 24-bit resolution, more information is captured from the original analogue sound wave form, giving a much richer audio reproduction.

Progressive Scan

Progressive Scan doubles the vertical resolution of the image resulting in a noticeably sharper picture. Instead of sending a field comprising the odd lines to the screen first, followed by the field with the even lines, it writes both fields at the same time. A full image is created instantaneously, using the maximum resolution. At such a speed, your eye perceives a sharper picture with no line structure.

One-touch MP3 creation

Convert the contents of your favourite CDs to MP3 files on your Philips product and store them directly on a thumb drive or on your portable media player through a USB cable. Enjoy the convenience of creating MP3 files right in your living room, without a PC and even while the CD is playing.

Hi-Speed USB 2.0 Link

The Universal Serial Bus or USB is a protocol standard that is conveniently used to link PCs, peripherals and consumer electronic equipment. Hi-Speed USB devices have a data transfer rate of up to 480 Mbps - up from the 12 Mbps of original USB devices. With Hi-Speed USB 2.0 Link, all you have to do is plug in your USB device, select the movie, music or photo and play away.



Issue date 2017-04-04

Version: 4.0.14

12 NC: 8670 000 36033
EAN: 87 12581 38705 1

© 2017 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com