



USB power bank

- 20,000 mAh
- 3 USB charging ports
- QC 3.0 and PD 3.0
- PPS

DLP7721C/00

Powerful power bank

with a portable back-up power pack

Big 20,000mAh capacity with safe Li-polymer battery. No more hassle when your cellphone is out of battery. Fast charge your device with USB-C PD 3.0 Max 20W or USB-A port with QC 3.0 Max 18W output.

Benefits

Superior Charging Design

- 3 USB ports charge three devices simultaneously
- USB-C PD 20W charging port
- USB-A with QC fast charging
- 50% charge in 30 minutes
- Charging using USB-C Programmable Power Supply (PPS)
- Smart protection against overheat, overvoltage & overcurrent

Portable power

- Works anywhere - great when you're not near a power source

Confirm operation at a glance

- LED power-indicator light

Features

USB-C PD 20W charging port.

Equipped with USB-C (Power Delivery) PD 20W fast charging port.

USB-A with QC fast charging

Quick Charge (QC) fast charging technology delivers faster charging by increasing voltage and current. It uses Quick Charge protocol to optimize charging speeds for compatible devices, reducing charge times

PHILIPS

50% charge in 30 min

Fast charging - Charge your mobile phone empty to 50% in 30 minutes time.

Programmable Power Supply PPS

PPS (Programmable Power Supply) is a standard for fast charging technology for USB-C devices. This technology adjusts the voltage and current in real-time, depending on a device's charging status, feeding it with maximum power. A smart way to safely reduce charging time.

Smart Protection

Smart protection against overheating, overvoltage and overcurrent

LED power-indicator light

The discreet LED light glows softly to let you know at a glance that the unit is powered.

Specifications

[field not found 'disclaimer_text']

Compatibility

Works with the following	USB charged devices
--------------------------	---------------------

Power

Output	USB-C Max 20W USB-A Max 18w [USB-C output:5V/3A, 9V/2.22A, 12V/1.67A, PD3.0+PPS, Max 20w USB-A output:5V/2.1A, 9V/2A, 12V/1.5A, QC3.0, Max 18W]
Power input	Type-C 5V/3A, MicroUSB 5V/2A [Micro USB input: 5V/2A,9V/2A USB-C input:5V/3A, 9V/2A, 12V/1.5A]
Battery Capacity	20,000mAh 74VWh [cell complies with IEC62133 certification]

Packaging dimensions

Number of products included	1
Type of shelf placement	Both
Height	17 cm
Width	9.5 cm
Depth	3.5 cm
Height	6.7 inch
Width	3.7 inch
Depth	1.4 inch
EAN	48 95229 13553 6

Outer Carton

Number of consumer packagings	18
Length	34 cm
Width	24 cm
Height	22.5 cm

Length	13.4 inch
Width	9.4 inch
Height	8.9 inch
GTIN	1 48 95229 13553 3

Inner Carton

Number of consumer packagings	6
Length	22 cm
Width	10.7 cm
Height	20.5 cm
Length	8.7 inch
Width	4.2 inch
Height	8.1 inch
GTIN	2 48 95229 13553 0

Accessories

User Manual	User Manual
Cables	USB-C charging cable

Product dimensions

Height	13.6 cm
Width	6.8 cm
Depth	2.75 cm
Height	5.4 inch
Width	2.7 inch
Depth	1.1 inch
Weight	0.355 kg
Weight	0.783 lb

Design and finishing

Materials	PC + ABS [Housing raw material meets UL 94-V0 Fire rating]
-----------	--



data subject to change
2023, September 27

Version: 3.3.2
EAN: 4895229135536

© 2023 Koninklijke Philips N.V.
All rights reserved.

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips N.V. or their respective owners.

www.philips.com