

Philips
Docking Entertainment
System



DC185

Enjoy iPod & MP3 music out loud anywhere you go

Free your iPod music and enjoy it out loud on the Philips DC185 with powerful 2 x 2 W sound. Share all your tunes and liven up any party or just plug in your USB device to enjoy your favourite music on the go.

Enrich your sound experience

- Play and charge your iPod
- USB Direct for MP3/WMA music playback

Superb performance in compact design

- Dynamic Bass Boost for deep and dramatic sound
- 2 x 2 W RMS total output power

Easy to use

- FM digital tuning with presets
- Aux-in connection for your portable MP3 music player

PHILIPS

Specifications

iPod compatibility

- Compatible with: iPod touch, iPod classic, iPod nano 3rd Generation, iPod 5th Generation, iPod with colour display, iPod mini, iPod nano 1st Generation, iPod nano 2nd Generation

Connectivity

- USB: USB host
- Aux in
- Headphones: 3.5 mm

Audio Playback

- Cradle playback mode: Charging iPod, Play and Pause, Next and Previous track, Fast forward and reverse
- Playback Media: USB flash drive
- Programmable Tracks: 20

Tuner/reception/transmission

- Tuner Bands: FM Stereo
- Tuner Enhancements: Auto Store
- Auto digital tuning
- Station presets: 20
- Antenna: FM Antenna

Sound

- Output power (RMS): 2 x 2 W
- Sound System: Stereo

- Sound Enhancement: Dynamic Bass Boost
- Volume Control: Volume Control up/down
- Speaker diameter: 3"

Loudspeakers

- Built-in speakers: 2

Convenience

- Display Type: LCD
- User convenience: Sleep Timer

Power

- Mains power
- Battery type: C/LR14 Alkaline
- Battery voltage: 1.5 V
- Number of batteries: 6

Accessories

- Included Accessories: AC Power Lead, 3.5 mm stereo line-in cable, User manual, Warranty certificate

Dimensions

- Product dimensions (W x H x D): 348 x 127 x 238 mm
- Packaging dimensions (W x H x D): 373 x 157 x 262 mm

Highlights

Dynamic Bass Boost

Dynamic Bass Boost maximises your music enjoyment by emphasising the bass content of the music throughout the range of volume settings - from low to high - at the touch of a button! Bottom-end bass frequencies usually get lost when the volume is set at a low level. To counteract this, Dynamic Bass Boost can be switched on to boost bass levels, so you can enjoy consistent sound even when you turn down the volume.

Play and charge your iPod

Play and charge your iPod



Issue date 2013-05-10

Version: 1.0.5

12 NC: 8670 000 41385
EAN: 87 12581 43527 1

© 2013 Koninklijke Philips Electronics N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.

www.philips.com