

Philips 2000 series
Multimedia Speakers 2.1

Bluetooth

Audio-in
USB

MMS2025



Music, Movies & Entertainment

These speakers are perfect for listening to music or watching movies at your home. The subwoofer packs a rich, punchy bass. The front-facing controls with USB plug and play, audio-in and FM radio add multiple ways to enjoy your content.

Experience true multimedia

- Compatible with music, games, film & internet audio sources

Rich, complex sound

- Subwoofer for deep bass plus satellites for clear highs
- Enjoy best-in-class performance and optimum sound quality
- Rich and dynamic sound from powerful drivers

Listen with pleasure

- Convenient speaker-front volume and power control

Simplicity

- Works with any Bluetooth-enabled device
- USB Direct for easy MP3 music playback
- Audio-in for easy connection to almost any electronic device
- FM tuner for radio enjoyment

PHILIPS

Highlights

Music, games, films, internet

All types of music, games, films and internet audio sources can be played, so no matter what you want to hear, we make your multimedia experiences sound more involving than ever.

Subwoofer + satellite speakers

The audio system is separated into a subwoofer that is optimized to reproduce bass frequencies and satellite speakers that are optimised for mid- and high-range frequencies. The result is a system that powerfully reproduces the full range of audio frequencies from deep bass to crystal clear high notes with the minimum of distortion.

Excellent sound quality

Acoustically-tuned design and high-quality drivers ensure best-in-class audio performance.

Speaker-front control

Convenient speaker-front volume and power control

Rich and dynamic sound

Powerful drivers deliver music that pack a solid punch, with deep and dynamic bass to keep you motivated. The premium quality drivers ensure a vivid sound experience.

Bluetooth-enabled



Bluetooth is a short range wireless communication technology that is both robust and energy-efficient.

The technology allows easy wireless connection to other Bluetooth devices, so you can play your favorite music from any smartphones, tablets or even laptops including iPod or iPhone on Bluetooth-enabled speaker easily.

USB Direct for easy MP3 music



Thanks to the complete file transferability, you can easily enjoy the convenience and fun of accessing more digital music via the built-in USB Direct.

Audio-in



Audio-in for easy connection to almost any electronic device

FM tuner

The built-in FM tuner lets you enjoy your favorite songs or news from your radio station every day. Simply tune into the station that you want to listen.

Specifications

Loudspeakers

- Satellite speaker drivers: 3"
- Subwoofer driver: 4"
- Subwoofer impedance: 4 ohm
- Speaker Impedance: 4 ohm

Connectivity

- Bluetooth range: Line of sight, 10M or 30FT
- Bluetooth version: 5.0

Accessories

- Included accessories: Remote Control with QWERTY, User Manual, Warranty Card, 3.5mm stereo line in cable

Dimensions

- Satellite: W9 x D7.5 x H22 cm
- Subwoofer: W22 x D14 x H26.8 cm
- Packaging dimensions (WxDxH): 28.8 x 31.5 x 26.6 cm
- Product weight: 3.5 kg
- Weight incl. Packaging: 3.8 kg

Power

- Power supply: 230VAC, 50Hz
- Power consumption: <8 W
- Standby power consumption: <1 W

Audio system

- Frequency range: 40 Hz to 20 KHz
- Output power in total: 50 W
- Signal/Noise ratio: >55 dB
- Speaker output power: 25 W
- Subwoofer output power: 10 W

Audio systems L/R channels

- Channel separation: >40 dB

Tuner/Reception/Transmission

- FM frequency range: 87.5 to 108 MHz

