

Philips
Cordless phone answer
machine



CD2554S

HD Sound

for natural voice clarity

The natural voice quality of HD Sound makes phone conversations even more lifelike.

The outstanding speakerphone brings the CD2 series to the heart of family life.

Conversations really can be shared with everyone.

Never miss a call

- Digital answering machine
- 15-minute recording time

Natural voice clarity

- HD sound
- Speakerphone - Talk hands-free

Pure convenience

- Bright illuminated display
- 100-name phonebook

PHILIPS
sense and simplicity

Specifications

Picture/Display

- Backlight
- Backlight colour: Amber
- Display colours: Black and White
- Lines of text: 1
- Main Display Technology: STN
- Main Display Type: Alphanumeric

Sound

- Handset ringers: Instrumental, Polyphonic
- Volume Control: Volume Control up/down

Convenience

- Alarms: Alarm Clock
- Base Station keys: Answering machine keys, Paging key
- Battery charging indication
- Call Management: Call Waiting, Caller ID, Conference Call, Explicit Call Transfer, Microphone mute
- Ease of Use: Full Duplex Hands-free, Keypad Lock, Menu Control
- Multi-base capability: 1
- Multi-handset capability: Up to 5 handsets
- Signal strength indication
- Backlit keypad: No
- Speakerphone - Talk hands-free

Network Features

- Antenna: Integrated on base, Integrated on handset

- Compatible: GAP
- Dialling: Tone, Pulse

Operator Requirements

- Name and Caller ID
- Caller ID on call waiting

Answering Machine

- Plug and Play Answering machine
- Recording time capacity: Up to 15 min.

Memory Capacity

- Call log entries: 20
- Phonebook: 100 names and numbers
- Redial List Capacity: 10

Dimensions

- Base dimensions: 118.5 x 113 x 82.5 mm
- Handset dimensions: 162 x 48 x 28.5 mm

Power

- Battery capacity: 600 mAh
- Battery type: AAA NiMH
- Kind of Battery: Rechargeable
- Mains power: AC 220-240 V - 50 Hz
- Number of batteries: 2 per handset
- Standby time: Up to 150 hours
- Talk time: Up to 12 hours

Highlights

HD sound

Enjoy high-quality conversation, with a level of clarity rarely heard before. Thanks to a high-quality speaker and to a real acoustic chamber, the audio spectrum reaches far beyond what's normally heard on a telephone.

Speakerphone - Talk hands-free

Hands-free mode uses a built-in loudspeaker to amplify the voice of the caller, allowing you to speak and listen during a call without holding the phone to your ear. This is especially useful if you want to share the call with others or take notes during a call.



Issue date 2012-02-07

Version: 1.0.4

12 NC: 8670 000 34881
EAN: 87 12581 37324 5

© 2012 Koninklijke Philips Electronics N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips
Electronics N.V. or their respective owners.

www.philips.com