

Philips Portable Radio

FM/MW/LW, Digital tuning

30 one touch presets Clock, Audio in Battery or AC operated

AE2800

# Enjoy your favorite radio

with one-touch access to preset stations

Boasting a built-in speaker that's loud yet high quality and FM/MW/LW tuning, this wood finished radio makes your favourite shows sound incredible. 30 station presets and a large backlit LCD display make it easy to use even in low light.

#### **Contemporary design**

• Premium wood-finished handle to suit modern home décor

### **Enjoy your favorite stations**

- FM / MW / LW digital tuner with 30 preset stations
- One-touch preset stations for extra convenience
- · Built-in speaker to enjoy radio out-loud in good sound

#### Easy to use

- Built-in clock function
- $\bullet$  Large backlit LCD display for easy viewing in low light
- · Low battery indicator keeping you informed of power level
- · Mains or battery operated for flexible placement
- Audio-in for easy portable music playback



FM/MW/LW, Digital tuning 30 one touch presets, Clock, Audio in, Battery or AC operated

## **Highlights**

#### Premium wood-finished handle

Premium wood-finished handle to suit modern home

FM / MW / LW digital tuner
The built-in FM/ MW/ LW digital tuner lets you enjoy your favorite songs or news from your radio station every day. Simply tune into the station that you want to preset, press and hold the program button to memorize the frequency. You can preset up to 30 radio stations and enjoy your favorite programs whenever you go.

#### **One-touch preset stations**

This radio comes with a total of 30 station presets (10 for the FM band, 10 for MW band and 10 for LW band) for added convenience. Once you have selected a station using the digital tuner, you can save it using one of the station preset buttons. To reach your desired station later on, simply press the same number preset button. There is no need to search for the station again using the digital tuner.

#### **Built-in speaker**



A speaker offers good sound quality for more

#### Large backlit LCD display



Backlit LCD display ensures easy viewing and operation in low light conditions, and provides clear information at a glance.

### **Built-in clock**

A built-in clock keeps time accurately. When the radio is off, the clock display comes on for added convenience.

#### Low battery indicator



The low battery indicator lights up when the power is low.

#### Mains or battery operated



Power your Philips radio set with batteries or a direct mains supply, and enjoy great convenience and flexibility. When a power socket is not available or when you don't want unsightly wires trailing, simply operate the set with batteries. When you need a continuous and stable power supply, connect the set directly to a wall socket. Now you can truly enjoy the freedom of listening wherever you like.

#### AUDIO-IN (3.5mm)



Make one easy connection and enjoy all your music from portable devices and computers. Simply plug your device to the AUDIO-IN (3.5 mm) port on your Philips set. With computers, the connection is typically made from the headset output. Once linked, you can enjoy your entire music collection directly, on a set of superior speakers. Philips simply delivers

## Specifications

#### Tuner/Reception/Transmission

- Tuner bands: FM, MW, LW
- Station presets: 30 (10 for each band)
- Auto digital tuning

#### Sound

- · Sound system: mono
- Output power: 1.2 W RMS
- Volume control: up/down

#### **Connectivity**

• Audio-in

#### Convenience

- · Display type: LCD display
- Backlight
- · Backlight color: white

- Power supply: 220 240 V
- Mains power: AC 5V, 1A
- Battery type: C size (LR14)
- · Number of batteries: 4
- Battery voltage: 1.5 V

#### **Accessories**

- AC Adapter
- · Quick start guide

#### **Dimensions**

- Main unit depth: 72 mm
- Main unit height: 161 mm
- · Main unit width: 242 mm
- · Product weight: 1.4 kg



Issue date 2014-06-11

Version: 1.1.4

12 NC: 8670 001 08017 EAN: 87 12581 70082 9 © 2014 Koninklijke Philips N.V. All Rights reserved.

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips N.V. or their respective owners.

www.philips.com