



Philips  
Portable CD Player

AX2401

## Jogproof

Irresistibly classic, the vibrant AX2401 CD players truly let you savor smooth, skip-free music. It flaunts an appealing round form and comes with a large display for convenient track viewing. It's designed to liven up your music on the go.

### **Jogproof**

- 45-second ESP™

### **Enhanced bass performance**

- Dynamic Bass Boost for deep and dramatic sound

### **Enjoy all kinds of discs**

- Play CD, CD-R and CD-RW discs

# PHILIPS

# Specifications

## Sound

- D/A converter: 1-bit
- Frequency response: 20 - 20 000 Hz
- Signal to noise ratio: > 85dB
- Sound Enhancement: Dynamic Bass Boost
- Output Power: 2 x 5mW RMS
- Volume Control: digital
- Acoustic Feedback

## Audio Playback

- Playback Media: CD, CD-R, CD-RW
- Disc Playback Modes: 30-Track Programmable, Fast Forward/Backward, Hold, Repeat Play, Resume Playback from stop, Shuffle Play, Scan
- Electronic Skip Protection(CD): 45

## Connectivity

- DC in: 4.0 mm, 4.5V, centre +
- Headphone: 3.5 mm
- Line-out: 3,5 mm

## Convenience

- Display Type: LCD
- Indications: battery status, Cd functions, DBB, ESP,



time, track

## Accessories

- Headphones: AY3806 earphones
- Included accessories: User Manual
- AC/DC Adaptor: AY3162(400mA)

## Dimensions

- Housing: Heat Resistant Body, Lenticular Sheet
- Master carton dimensions: 310 x 162 x 252 mm
- Master carton weight: 4.18 kg
- Master carton quantity: 6
- Packaging dimensions (W x H x D): 243 x 49 x 148 mm
- Packaging type: D-box
- Product dimensions (WxDxH): 140x140x27.5mm
- Product weight: 0.2 kg

## Power

- Battery Playing Time CD: 20
- Battery type: AA, LR6, UM3

# Highlights

## 45-second ESP™

Electronic Skip Protection is a convenient feature that ensures skip-free music even when your CD player is subjected to knocks and jolts while you're jogging or on the move. Devices with Electronic Skip Protection have an intelligent electronic buffer that adjusts both its contents and laser spin speeds automatically to guarantee uninterrupted music listening.

## Dynamic Bass Boost

Dynamic Bass Boost maximizes your music enjoyment by emphasizing the bass content of the music throughout the range of volume settings - from low to high - at the touch of a button! Bottom-end bass frequencies usually get lost when the volume is set at a low level. To counteract this, Dynamic Bass Boost can be switched on to boost bass levels, so you can enjoy consistent sound even when you turn down the volume.

## Play CDs, CD-R and CD-RW

Philips is known for making products which are compatible with many discs available in the market. This audio system lets you enjoy music from CD, CD-R and CD-RW. CD-RW (CD-Rewritable Compatible) means that your audio system can play both CD-Recordable (CD-R) and CD-Rewritable (CD-RW) discs. CD-R discs are recordable once and can be played on any audio CD player while CD-RW discs can be recorded and rewritten multiple times and can only be played back on compatible audio CD players.



Issue date 2014-02-13

Version: 3.0.5

12 NC: 9073 101 01729  
EAN: 87 10895 86821 1

© 2014 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)